

MITSUBISHI GENUINE PARTS

“MITSUBISHI GENUINE PARTS” should be used exclusively for servicing your Mitsubishi engine.

“MITSUBISHI GENUINE PARTS” are superior and reliable because they have been produced under the excellent quality-control system, and have passed the strict inspections.

Imitation parts are not reliable from the viewpoints of their material and manufacturing method which are entirely incomparable with those of genuine parts.

A large assortment of “MITSUBISHI GENUINE PARTS” is always available at any of our authorized dealers, so do your ordering at your nearest dealer by specifying “MITSUBISHI GENUINE PARTS”.

GUIDE FOR USE OF PARTS CATALOGUE

1. This Parts Catalogue contains service parts for the following Mitsubishi S4S diesel engine.
The applicable engine types and serial number are as follows:

ENGINE NAME	MODEL	USE · SPECIFICATION	APPLICABLE SERIAL NO.
S4S	Y262IR	For Generator	131870-UP
	Y362IR		XXXXXX-UP

2. When ordering parts, give the Mitsubishi dealer or distributor the following information:
(1) Part number (or assembly number) and part name.
(2) Quantity required
(3) Model and serial number
NOTE: In some cases a substitute part is furnished instead of the part ordered.
3. Indication of assembled bolts with washer
Of the standard bolts, those with washers are identified by the symbol "B/W" in the Description column of each list. (Part Name: BOLT, W/WASHER)
For the part numbers of the bolts and washers and those of bolts with washers, refer to the listing (beginning with the page D1) at the end of this parts catalogue. These bolts and washers should be ordered individually.
4. Indication of combination for replaceability — "G"—
The new part to be used in combination with the other part in place of an old part is identified by the symbol "G" in the interchangeability code column of each list.
For the parts to be combined, refer to the listing (beginning with E1) at the end of this parts catalogue.
5. For the numerical index, refer to the page beginning with C1 at the end of this parts catalogue.
6. Some illustration may have some difference from the real part shape when the illustration Shows a representation of various parts.
7. The parts and part numbers are subject to change without prior notice.

SAMPLE OF PARTS CATALOGUE

Group number

Group name

07-01 CRANKCASE ASSY

Model type

When these column is blank, it is applicable from serial No. shown on cover and up.

Not applicable to the model of this column.

REF. -NO.	PART NO.	R / P	S C E N G	PART NAME & DESCRIPTION	MODEL&QTY			APLICABLE SERIAL NO. FROM@ -@UPTO	M / R D
					Y262IR	Y362IR			
1	32507-70010			CRANKCASE ASSY	1	1			
1 01	F2846-14000			PIN,DOWEL	4	.			A
1 02	32507-01400			WASHER	14	14			A
1 03	*			CAP,MAIN BEARING	6	6			
1 04	*			CAP,MAIN BEARING	1	1			
1 05	*			CRANKCASE	1	1			
2	32507-02500		C	HANGER	1	1		-111285	V
	32507-02700	N 1		HANGER	1	1		111286-	
3	32507-04100		Q	SHIM	.	.		@111294	
	32507-04100	1		SHIM	3	3		111295@	
4	F1805-10025			BOLT,W/WASHER	2	2			A

See(8)-(a)Description Codes.

See(8)-(c)Specification Codes.

See(8)-(b)Description.

See(6)Change codes.

See(5)Sequence-of-change numbers.

See(2)Reference number.

See(4)Interchangeability codes.

Part not to be supplied See(3).

Quantity per unit.

Applicable from serial No. indicated.

Applicable from 111295 (Scheduled)if suffixed with @ and sometimes differs from real serial No.

Applicable up to serial No. indicated.

High-demand part. See(11).

Part newly changed or added. See(12).

Applicable up to 111294 (Scheduled)if prefixed with @ and sometimes differs from real serial No.

NOTE: Some of model designations, number of variations and serial numbers, indicated above, are quoted from other parts catalogues.
Read these items of information as those for this parts catalogue.

NOTE: For the description of each item, refer to the pages which follow.

HOW TO USE THIS PARTS CATALOGUE

(to be referred to together with the former SAMPLE OF PARTS CATALOGUE)

01 CYLINDER HEAD

- 3 -

REF. -NO.	PART NO.	R / P	S C E N P Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R D	V R D
					Y2621R	Y3621R		FROM	TO		
1	32A01-11020		C	HEAD ASSY, CYLINDER	1	1			@179577		V
2	32A01-21020	3	1	HEAD ASSY, CYLINDER	1	1					
2	*			HEAD SUB ASSY, CYL	1	1					
2 01	04826-22000			CAP, SEALING	8	8					
2 02	04826-22500			CAP, SEALING	7	7					

(2) (3) (4)(5)(6) (7) (8) (9) (10) (11)(12)

The items (1) thru (12) are as described below:

(1) Compiling system

The systems of a unit are grouped according to their location in the unit. The groups, each identified by group number, are listed in the order by CONTENTS. Each group is preceded by an "exploded view" which clearly illustrates each part in its correct relation to the other parts in the illustration.

(2) Reference number

Abbreviated to "REF. No.", this number is used to locate a part in the illustration. In cases where the reference number is of three to four digits, the first and second digits show the reference number of an assembly, and the last two digits show the numbers of its component parts.

(3) Part numbers

The part numbers shown in this parts catalogue are those assigned to genuine Mitsubishi parts.

NOTE : Parts with asterisk (*) are not supplied individually.

(4) Interchangeability codes

The interchangeability codes used in this parts catalogue are as follows:

PARTS NO.	Code (R/ P)	DESCRIPTION
A(Old) B(New)	R	B(new part) and A(old part) are mutually interchangeable
A(Old) B(New)	1	A(Old part) is not supplied. B(new part) can be substituted for A(Old part).
A(Old) B(New)	3	B(new part) can be substituted for A(old part). [A(old part) cannot be substituted for B(new part).]
A(Old) B(New)	N	B(new part) and A(old part) are not interchangeable.
A(Old) B(New)	G	B(new part) can be substituted for A(old part) in combination with other part(s). (For the parts to be combined, refer to the listing beginning with the page E1 at the end of this parts catalogue.)

(5) Sequence-of-change numbers

The parts are changed for improved quality or performance. Their changes are indicated in sequence by numerals (1 . 2 . 3...).

Blank : Original

1 : 1st change

2 : 2nd change

3 : 3rd change

(6) Change codes

These codes indicate the reason or purpose of changes of the parts.

A : Added part (a part entered into service)

C : Change of part number

D : Deleted part (a part applicable up to the serial no. expressed in Serial No. column)

E : Added part except above reasons

Q : Change of quantity

(7) Part name

Abbreviations are sometimes used. For the abbreviations, refer to TABLE OF SYMBOLS & ABBREVIATIONS appeared in hide pages of this general information chapter.

NOTE: The location terms LH (left hand) and RH(right hand) are as these directions viewed from the flywheel side of an engine.

(8) Description & specification codes

(a) Description codes (expressed in the first part of Description column).

B/W: Assembled bolt (with washer)

KIT: Part supplied as a kit

STD: Standard part

OPT: Optional part

AR : Part used, as required or by selection or in adjust quantity for necessity

SFN: Semi-finished part

(b) The Description codes in above paragraph (a) are followed by supplementary explanation such as dimensions (thickness, length, etc.) ,manufacturer part number, manufacturer name, etc. as occasion demands.

NOTE: Unless otherwise indicated, the dimensions are shown in millimeter and the name of unit is abbreviated.

(Examples) Thickness: T=1.00 Length: L=1000

Width: W=1500 Height: H=500

(c) Specification codes

Each specification or type of model and/or selective specifications of a unit are indicated by codes of three figures. For these codes, refer to LIST OF SPECIFICATION CODES appeared in hind pages of this general information chapter.

NOTE: Unless indicated by the specification codes, the parts may be used for the products of all specifications.

(Examples) A10:For diesel fuel
B10:With industrial electric starter

- (d) The parts indicated as "NOT SHOWN", such as component parts of overhaul gasket kit, are not shown in the illustration.

(9) Model & quantity

- (a) Model : Model, type, specification, destination, etc. of product to which a parts catalogue applies are indicated in the title column of each variation.
- (b) Quantity :Quantity of part or assembly and its component parts required for one unit of product is indicated.

NOTE : In case "AR" appears in QTY column, it is required to adjust quantity for use.

(10) Applicable serial numbers

Applicable serial numbers of engine are indicated in the "UPTO" or "FROM" column. Serial numbers with "@" are scheduled ones and sometimes differ from the real serial numbers. If the "FROM " column is blank, the part is applicable to serial number shown on this cover and up.

(11) Management rank

Parts ranked as "A" are high-demand parts. This ranking is to be referred to by dealers, and is devised to facilitate and rationalize their distribution, stocking and inventory of the parts.

- (12) Parts changed or added after the last parts list that has been published are identified by "V."

TABLE OF SYMBOLS & ABBREVIATIONS

SYMBOL	DESCRIPTION		SYMBOL	DESCRIPTION	
ACCEL	ACCELERATOR		ELEC	ELECTRIC	
ADJ	ADJUSTING (ADJUSTABLE)		ENG	ENGINE	
AIR-CON	AIR-CONDITIONER		EQUIP	EQUIPMENT	
ASSY	ASSEMBLY		EXH	EXHAUST	
ATT	ATTACHMENT		E/TNK	EXPANSION TANK	
AUTO	AUTOMATIC		FITT	FITTING	
AUX	AUXILIARY		FLEX	FLEXIBLE	
AR	AS REQUIRED		FR	FRONT	
B/H	BACKHOE		GSKT	GASKET	
BATT	BATTERY		GEN	GENERATOR	
BRG	BEARING		GOV	GOVERNOR	
B/PMP	BILGE PUMP		G/N	GROUP NUMBER	
BRKT	BRACKET		H/EXCH	HEAT EXCHANGER	
BUSH	BUSHING		HEX	HEXAGON	
CARB	CARBURETOR		HYD	HYDRAULIC	
C/L	CENTERLINE		H=	HEIGHT	
COMPR	COMPRESSOR		IND	INDUSTRIAL	
CON-ROD	CONNECTING-ROD		INJ	INJECTION	
C/MBR	CROSS-MEMBER		INSTAL	INSTALLATION	
CYL	CYLINDER		INST	INSTRUMENT	
DIA	DIAMETER		INTLK	INTERLOCK	
DIFF	DIFFERENTIAL		JUNC	JUNCTION	
DISTR	DISTRIBUTOR		KD	KNOCKDOWN	
DR	DRIVE		L.H	LEFT HAND	
D=	OUT DIAMETER		LUB	LUBRICATION	
			L=	LENGTH	

TABLE OF SYMBOLS & ABBREVIATIONS

SYMBOL	DESCRIPTION		SYMBOL	DESCRIPTION	
MANF	MANIFOLD		STD	STANDARD	
MAX	MAXIMUM		SUPT	SUPPORT	
MIN	MINIMUM		SYM	SYMBOL	
MTR	MOTOR		SYNCH	SYNCHRONIZER	
MTG	MOUNTING		SYS	SYSTEM	
			TEMP	TEMPERATURE	
NO.	NUMBER		TERM	TERMINAL	
OPT	OPTION		T/CONV	TORQUE-CONVERTER	
O/D	OVER DRIVE		T/F	TRANSFER	
O.S	OVERSIZE		T/M	TRANSMISSION	
PTO	POWER TAKE-OFF		T/HSG	TURBINE-HOUSING	
P/S	POWER STEERING		T/C	TURBOCHARGER	
PRESS	PRESSURE		T=	THICKNESS	
P/N	PART NUMBER		U/BODY	UNDERBODY	
QTY	QUANTITY		U.S	UNDERSIZE	
			UNIV	UNIVERSAL	
RAD	RADIATOR		VAC	VACUUM	
RE	REAR		VENT	VENTILATOR	
REG	REGULATOR		W/STRIP	WEATHERSTRIP	
REV	REVERSE		W/	WITH	
R.H	RIGHT HAND		W/O	WITHOUT	
REF.NO.	REFERENCE		W/W	WOODWARD	
R/N	REFERENCE		W/PMP	WATER PUMP	
S/PMP	SEA WATER PUMP		W=	WIDTH	
SECT	SECTION		Z=	NUMBER OF GEAR TEETH	
S/MBR	SIDEMEMBER				

TABLE OF SYMBOLS & ABBREVIATIONS


SYMBOL	DESCRIPTION		SYMBOL	DESCRIPTION	
1ST	FIRST				
2ND	SECOND				
3RD	THIRD				
4TH	FOURTH				
5TH	FIFTH				
&	AND				
@	UNCONFIRMED				
*	PART NOT TO BE SUPPLIED				

CONTENTS


GROUP NO .	GROUP NAME	PAGE
ENGINE BODY		
01	CYLINDER HEAD	2
01-02	LIFTING EYE	4
04	VALVE MECHANISM	6
04-02	ROCKER COVER	8
05	CAMSHAFT & TAPPET	10
07	CRANKCASE ASSY	12
09	MAIN METAL	14
11	TIMING GEAR CASE	16
12	FLYWHEEL HOUSING	18
13	OIL PAN & OIL LEVEL GAGE	20
17	PISTON	22
19	CONNECTING ROD	24
20	CRANKSHAFT	26
20-02	CRANK PULLEY	28
21	FLYWHEEL	30
23	TIMING GEAR	32
INLET & EXHAUST SYSTEM		
30	INLET SYSTEM	34
30-02	INLET PIPE	36
32	EXHAUST SYSTEM	38

GROUP NO .	GROUP NAME	PAGE
OIL SYSTEM		
35	OIL PUMP	40
35-02	OIL STRAINER	42
36	OIL SYSTEM	44
39	OIL COOLER	46
40	OIL FILTER	48
43	BREATHER	50
COOLING SYSTEM		
45	WATER PUMP	52
45-02	WATER PUMP PULLEY	54
46	COOLING SYSTEM	56
47-00-01	RADIATOR(FOR Y2621R)	58
47-00-02	RADIATOR(FOR Y3621R)	60
48	FAN	62
48-02	FAN SPACER	64
49	V-BELT	66
FUEL SYSTEM		
61-00-01	FUEL SYSTEM	68
61-00-02	NOZZLE	70
62	FUEL FILTER	74
65-01-01	INJECTION PUMP	76
65-01-02	PUMP ASSY INJECTION (FOR Y2621R)	78
65-01-03	PUMP ASSY INJECTION (FOR Y3621R)	80

GROUP NO .	GROUP NAME	PAGE
65-01-04	INJECTION PUMP BODY ASSY	82
65-01-05	GOVERNOR ASSY(FOR Y2621R)	86
65-01-06	GOVERNOR ASSY(FOR Y3621R)	90
65-01-07	FEED PUMP	94
ELECTRIC PARTS		
66	STARTER(12V-2.2KW)	96
66-02	GLOW PLUG & WIRE	98
68-00-01	ALTERNATOR	100
68-00-02	ALTERNATOR(12V-50A)	102
CONTROL SYSTEM		
87-05	CONTROL SYSTEM	104
ACCESSORY		
92	ACCESSORY	106
REPAIR PARTS		
94	OVERHAUL GASKET KIT	108
NUMERICAL PARTS INDEX		C1
TABLE OF BOLT,W/WASHER		D1










REF. NO. 5 COMES IN PAIRS.


REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A04-20100			VALVE, INLET	4	4					
2	32A04-21100			VALVE, EXHAUST	4	4					
3	30604-21402			SPRING, VALVE	8	8				A	
4	30604-31601			RETAINER, UPPER	8	8					
5	34404-02901			COTTER, VALVE	16	16				A	
6	31304-11700			CAP	8	8					
7	32A04-02801			SEAL, VALVE STEM	8	8				A	
8	*			ROCKER & SHAFT ASSY	1	1					
8 01	32A04-22010			ROCKER ASSY	8	8					
8 02	F2325-08000			NUT, JAM	8	8				A	
8 03	*			ROCKER & BUSHING	8	8					
8 04	32A04-02401			SCREW, ROCKER	8	8					
8 05	32C04-04501			SPRING, ROCKER	3	3					
8 06	32A04-04011			SHAFT ASSY, ROCKER	1	1					
8 07	*			SHAFT, ROCKER	1	1					
8 08	04826-21200			CAP, SEALING	2	2					
8 09	MF522010			RING, SNAP	2	2				A	
8 10	32A04-04701			BRACKET, ROCKER SHAFT	4	4					
8 11	32A04-04801			BOLT, ROCKER BRACKET	4	4					
8 12	MF241255			BOLT, W/WASHER	4	4				A	










REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1	32A07-21010		C	CRANKCASE ASSY	1	•			@147277		
	32A07-31010	3	1 C	CRANKCASE ASSY	1	•					V
	32A07-41010	R	2	CRANKCASE ASSY	1	1					V
2	*			CRANKCASE SUB ASSY	1	1					
2 01	04826-23500			CAP, SEALING	10	10					
2 02	*			CAP, BEARING	4	4					
2 03	*			CAP, BEARING REAR	1	1					
2 04	32A07-02600			BOLT, BEARING CAP	10	10				A	
2 05	*			CRANKCASE	1	1					
3	04826-21800	Q		CAP, SEALING	5	5			@147277		
	04826-21800	1		CAP, SEALING	4	4		147278@			
4	*			PLUG	3	3					
5	34307-02100			PLUG, CAM	1	1					
6	32A07-01501			PIN, DOWEL	2	2				A	
7	F2846-12000			PIN, DOWEL	2	2				A	
8	F2846-05000			PIN, DOWEL	2	2				A	
9	F2850-04008			PIN, SPRING	6	6				A	
10	05605-01410		C	BUSHING	1	1					
	05660-01410	R	1	BUSHING	1	1					V
11	32A23-03500			SHAFT, IDLER	1	1					
12	32A07-11700			SEAL, SIDE	2	2				A	
13	MD000269			PLUG, TAPERED	1	1				A	
14	MS661140			PLUG, TAPERED	7	7				A	
15	MS661142			PLUG, TAPERED	1	1				A	
16	04827-90170	A		PLUG, TAPERED	1	1		147278@		A	V




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION		MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A09-00010			METAL SET, MAIN	STD	1	1				A	
1 01	*			METAL, MAIN LOWER		5	5					
1 02	*			METAL, MAIN UPPER		5	5					
2	32A09-00020			METAL SET, MAIN	U.S 0.25	1	1				A	
3	32A09-00030			METAL SET, MAIN	U.S 0.50	1	1				A	
4	32A09-00040			METAL SET, MAIN	U.S 0.75	1	1				A	
5	32B09-08101			PLATE, THRUST	STD	3	3					
6	32B09-08201			PLATE, THRUST	O.S 0.15	3	3					
7	32B09-08301			PLATE, THRUST	O.S 0.30	3	3					




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A11-03100		C	PLATE,FRONT	1	•			@179577		
	32A11-13100	3	1 C	PLATE,FRONT	1	•					V
	32A11-23100	R	2	PLATE,FRONT	1	1					V
2	32A07-04100			GASKET,FRONT PLATE	1	1				A	
3	MF241251			BOLT,W/WASHER	5	5				A	
4	32A11-00105		C	CASE,TIMING GEAR	1	•			@179577		
	32A11-10100	3	1	CASE,TIMING GEAR	1	1					V
5	32A11-00200			GASKET,GEAR CASE	1	1				A	
6	MF241264			BOLT,W/WASHER	13	13				A	
7	32A11-01100			COVER,TIMING GEAR	1	1					
8	06016-13140			O-RING	1	1				A	
9	MF241266			BOLT,W/WASHER	5	5				A	
10	32A11-04010			SEAL ASSY,OIL	1	1				A	





REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32B12-20103	R	1	HOUSING, FLYWHEEL	1	•					
	32B12-20104			HOUSING, FLYWHEEL	1	1					V
2	32A07-14201			GASKET, REAR	1	1				A	
3	MF241282			BOLT, W/WASHER	10	10				A	
4	MF241284			BOLT, W/WASHER	2	2				A	
5	34407-11090			SEAL ASSY, OIL	1	1				A	
6	MF407726			STUD	2	2					
7	F2515-10000			WASHER, SPRING	2	2				A	
8	F2300-10000			NUT	2	2				A	
9	MM316248			PLUG, DRAIN	1	1				A	
10	30636-25901			GASKET	1	1				A	
11	MD000312			GASKET	1	1				A	
12	MD001404			PLUG	1	1				A	







REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A17-08300			PIN,SNAP	4	4				A	
2	F3202-03000			RING,SNAP	8	8				A	
3	32A17-10100			PISTON	4	4				A	
4	32A17-10200			PISTON	4	4				A	
5	32A17-10300			PISTON	4	4				A	
6	32A17-02010			RING SET,PISTON	4	4				A	
6 01	*			RING,NO.1	4	4					
6 02	*			RING,NO.2	4	4					
6 03	*			RING,OIL	4	4					
7	32A17-02020			RING SET,PISTON	4	4				A	
8	32A17-02030			RING SET,PISTON	4	4				A	






REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A20-00014			CRANKSHAFT ASSY	1	1					
1 01	32A20-02901		C	NUT, CRANKSHAFT	1	•			@200507		
	32A20-02902	3	1	NUT, CRANKSHAFT	1	1					V
1 02	F2846-10000			PIN, DOWEL	2	2				A	
1 03	F2870-07022			KEY, WOODRUFF	2	2					
1 04	*			CRANKSHAFT	1	1					
1 05	32A23-00101			GEAR, CRANKSHAFT	1	1					






REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION		MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A21-00051			FLYWHEEL ASSY		1	1					
1 01	32A21-00900			GEAR,RING	Z=122	1	1					
1 02	*			FLYWHEEL		1	1					
2	F1035-12035			BOLT		4	4				A	
3	F2515-12000			WASHER, SPRING		4	4				A	





REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION		MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A23-01100	R	1	GEAR,CAMSHAFT	Z=46	1	•					
	32A23-01101			GEAR,CAMSHAFT	Z=46	1	1					V
2	32A23-12301			GEAR, INJ PUMP	Z=46	1	1					
3	32A23-03010			IDLER ASSY, GEAR	Z=49	1	1					
3 01	*			GEAR, IDLER		1	1					
3 02	32A23-03200			BUSHING, IDLER		1	1					
4	34323-00801			PLATE, THRUST		1	1					
5	MF241280			BOLT, W/WASHER		1	1				A	
6	32A35-12101			GEAR, OIL PUMP	Z=31	1	1					





REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A30-16012			MANIFOLD ASSY, INLET	1	1					
1 01	32A04-09100			PIPE, BREATHER	1	1					
1 02	*			MANIFOLD, INLET	1	1					
2	32A30-00201			GASKET, INLET MANF	1	1				A	
3	MF241261			BOLT, W/WASHER	14	14				A	
4	F1035-08090			BOLT	2	2				A	
5	F2515-08000			WASHER, SPRING	2	2				A	

30-02 INLET PIPE












REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A35-16101			STRAINER,OIL	1	1					
2	F3150-02000			O-RING	1	1				A	
3	MF241251			BOLT,W/WASHER	2	2				A	







REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A39-01100			COVER, SIDE	1	1					
2	32A39-11200		C	GASKET, SIDE COVER	1	•			@190874	A	
	32A39-21200	3	1	GASKET, SIDE COVER	1	1				A	V
3	MF240051			BOLT, W/WASHER	14	14				A	




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A40-00100		C	CARTRIDGE,OIL	1	•			@148365		
	32A40-10100	3	1	C CARTRIDGE,OIL	1	•			@153487		V
	32A40-00400	N	2	CARTRIDGE,OIL	1	1		153488@			V
2	32A40-01100		C	UNION,OIL FILTER	1	•			@153487		
	32A40-01101	3	1	UNION,OIL FILTER	1	1					V







REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A45-10030		C	PUMP ASSY, WATER	1	•					
1 01	32A45-10031	R	1	PUMP ASSY, WATER	1	1					V
1 02	32A45-00300			COVER, WATER PUMP	1	1					
	32A45-00400		C	GASKET, PUMP COVER	1	•			@188693	A	
	32A45-10400	3	1	GASKET, PUMP COVER	1	1				A	V
1 03	MF140231			BOLT, FLANGE	1	1				A	
1 04	32A45-01600			PLUG, TAPERED	1	1				A	
1 05	MH001401			BOLT, FLANGE	2	2				A	
1 06	*			PIPE, WATER PUMP	1	1					
1 07	*			CASE, WATER PUMP	1	1					
2	32A45-00500		C	GASKET, WATER PUMP	1	•			@188693	A	
	32A45-10500	3	1	GASKET, WATER PUMP	1	1				A	V
3	MF241262			BOLT, W/WASHER	4	4				A	
4	MF241266			BOLT, W/WASHER	1	1				A	



REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A45-02100			PULLEY,WATER PUMP	1	1					
2	MF243648			BOLT,W/WASHER	4	4				A	



REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A46-02100			THERMOSTAT	1	1					
2	32A46-02050			CASE ASSY, THERMOSTAT	1	1					
2 01	*			PIPE, THERMOSTAT	1	1					
2 02	*			CASE, THERMOSTAT	1	1					
3	32A46-01800			GASKET, THERMO CASE	1	1				A	
4	MF241268		C	BOLT, W/WASHER	1	•			@188693	A	
	MF140239	3	1	BOLT, FLANGE	1	1				A	V
5	MF240062		C	BOLT, W/WASHER	1	•			@188693	A	
	MF140433	3	1	BOLT, FLANGE	1	1				A	V
6	32A46-02600			HOSE, BY-PASS	1	1					
7	05317-50301			CLAMP, HOSE	2	2					
8	MM316248			PLUG, DRAIN	2	2				A	
9	30636-25901			GASKET	2	2				A	
10	32A46-01400			GASKET, THERMOSTAT	1	1				A	
11	MF140227			BOLT, FLANGE	2	2				A	
12	32A46-01101			COVER, THERMOSTAT	1	1					




47-00-01 RADIATOR(FOR Y262IR)

- 59-


REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1	32A47-05010			RADIATOR ASSY	1	•					
1 01	32A47-05800			SHROUD	1	•					
1 02	42786-03300			CLIP,HOSE	1	•					
1 03	32A47-06100			HOSE	1	•					
1 04	F1825-06012			BOLT,W/WASHER	4	•				A	
1 05	42713-30600			CAP,PRESSURE	1	•					
1 06	32A47-05600			CUSHION	2	•					
1 07	32A47-05700			COLLAR	2	•					
1 08	32A47-05900			PACKING	2	•				A	
2	32A47-02700			HOSE,RUBBER	1	•					
3	32A47-02800			HOSE,RUBBER	1	•					
4	05317-01600			CLAMP,HOSE	2	•					
5	31A47-03100			CUSHION	2	•					
6	31A47-03500			COCK ASSY	1	•					
7	42786-03300			CLIP,HOSE	1	•					
8	05317-01700			CLAMP,HOSE	2	•					

2009-02-25


610337-01




REF. -NO.	PART NO.	R / P	S C E N E Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1	32A47-05011		A	RADIATOR ASSY	•	1					V
1 01	32A47-05801		A	SHROUD	•	1					V
1 02	42786-03300		A	CLIP, HOSE	•	1					V
1 03	32A47-06100		A	HOSE	•	1					V
1 04	MF244826		A	BOLT, W/WASHER	•	4				A	V
1 05	42713-30600		A	CAP, PRESSURE	•	1				A	V
1 06	32A47-05600		A	CUSHION	•	2					V
1 07	32A47-05700		A	COLLAR	•	2					V
2	32A47-02700		A	HOSE, RUBBER	•	1					V
3	32A47-02800		A	HOSE, RUBBER	•	1					V
4	05317-01600		A	CLAMP, HOSE	•	2					V
5	31A47-03100		A	CUSHION	•	2					V
6	31A47-03500		A	COCK ASSY	•	1					V
7	42786-03300		A	CLIP, HOSE	•	1					V
8	05317-01700		A	CLAMP, HOSE	•	2					V




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION		MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y2621R	Y3621R		FROM@-	-@UPTO		
1	31345-12100			PLATE		1	1					
2	32A48-00400			FAN		1	1					




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION		MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y2621R	Y3621R		FROM@-	-@UPTO		
1	32C48-01105			SPACER, FAN		1	1					
2	MF241261			BOLT, W/WASHER		4	4				A	







REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32C61-06000			NOZZLE ASSY	SEE G/N 61-00-02	4	4			A	
2	MD068353			NUT		4	4			A	
3	MD068355			GASKET, FUEL RETURN		4	4			A	
4	MD070717			GASKET, HOLDER		4	4			A	
5	MM430703			CLAMP		3	3				
6	MM430614			CLAMP		3	3				
7	MF243628			BOLT, W/WASHER		3	3			A	
8	32A61-04100			PIPE, FUEL LEAK OFF		1	1				
9	32A61-03700			PIPE, FUEL RETURN		1	1				
10	MF240049			BOLT, W/WASHER		1	1			A	
11	30661-50802			JOINT, EYE		1	1				
12	32A61-04700			HOSE, FUEL		1	1				
13	ME910-12501			PIPE		1	1				
14	32A61-03901			CLAMP, PIPE		1	1				
15	32B61-02100			PIPE, INJECTION NO, 1		1	•				
16	32B61-02200			PIPE, INJECTION NO, 2		1	•				
17	32B61-02300			PIPE, INJECTION NO, 3		1	•				
18	32B61-02400			PIPE, INJECTION NO, 4		1	1				
19	32A61-59100	A		PIPE, INJECTION NO, 1		•	1				V
20	32A61-59200	A		PIPE, INJECTION NO, 2		•	1				V
21	32A61-59300	A		PIPE, INJECTION NO, 3		•	1				V




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1	32C61-06000			NOZZLE & HOLDER ASSY	4	4					
1 01	32C61-06010			HOLDER ASSY,NOZZLE	4	4					
1 02	09311-05480			BODY SUB ASSY	4	4					
1 03	09312-10380			PIN,PRESSURE	4	4					
1 04	09312-70360			SPRING,PRESSURE	4	4				A	
1 05	09316-41351			NUT,NOZZLE RETAINING	4	4					
1 06	09317-40070			PIECE,DISTANCE	4	4					
1 07	09317-51670			WASHER T=0.900	AR	AR				A	
	09317-51680			WASHER T=0.925	AR	AR				A	
	09317-51690			WASHER T=0.950	AR	AR				A	
	09317-51700			WASHER T=0.975	AR	AR				A	
	09317-51710			WASHER T=1.000	AR	AR				A	
	09317-51720			WASHER T=1.025	AR	AR				A	
	09317-51730			WASHER T=1.050	AR	AR				A	
	09317-51740			WASHER T=1.075	AR	AR				A	
	09317-51750			WASHER T=1.100	AR	AR				A	
	09317-51760			WASHER T=1.125	AR	AR				A	
	09317-51770			WASHER T=1.150	AR	AR				A	
	09317-51780			WASHER T=1.175	AR	AR				A	
	09317-51790			WASHER T=1.200	AR	AR				A	
	09317-51800			WASHER T=1.225	AR	AR				A	
	09317-51810			WASHER T=1.250	AR	AR				A	
	09317-51820			WASHER T=1.275	AR	AR				A	
	09317-51830			WASHER T=1.300	AR	AR				A	
	09317-51840			WASHER T=1.325	AR	AR				A	
	09317-51850			WASHER T=1.350	AR	AR				A	
	09317-51860			WASHER T=1.375	AR	AR				A	
	09317-51870			WASHER T=1.400	AR	AR				A	
	09317-51880			WASHER T=1.425	AR	AR				A	
	09317-51890			WASHER T=1.450	AR	AR				A	
	09317-51900			WASHER T=1.475	AR	AR				A	
	09317-51910			WASHER T=1.500	AR	AR				A	
	09317-51920			WASHER T=1.525	AR	AR				A	
	09317-51930			WASHER T=1.550	AR	AR				A	
	09317-51940			WASHER T=1.575	AR	AR				A	
	09317-51950			WASHER T=1.600	AR	AR				A	
	09317-51960			WASHER T=1.625	AR	AR				A	
	09317-51970			WASHER T=1.650	AR	AR				A	
	09317-51980			WASHER T=1.675	AR	AR				A	
	09317-51990			WASHER T=1.700	AR	AR				A	
	09317-52000			WASHER T=1.725	AR	AR				A	
	09317-52010			WASHER T=1.750	AR	AR				A	
	09317-52020			WASHER T=1.775	AR	AR				A	
	09317-52030			WASHER T=1.800	AR	AR				A	
	09317-52040			WASHER T=1.825	AR	AR				A	
	09317-52050			WASHER T=1.850	AR	AR				A	
	09317-52060			WASHER T=1.875	AR	AR				A	
	09317-52070			WASHER T=1.900	AR	AR				A	
	09317-52080			WASHER T=1.925	AR	AR				A	
	09317-52090			WASHER T=1.950	AR	AR				A	




610337-01





REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A61-01201			FLANGE, INJ PUMP	1	1					
2	06016-13140			O-RING	1	1				A	
3	30661-51300			GASKET, INJ PUMP	1	1				A	
4	F2015-10035			BOLT, W/WASHER	4	4				A	
5	MF241253			BOLT, W/WASHER	1	1				A	
6	F4440-06300			CONNECTOR	1	1					
7	32A36-30100			PIPE, OIL	1	1					
8	32A61-00900			BRACKET, INJ PUMP	1	1					
9	32A13-02700			BOLT, FLANGE	1	1				A	
10	F2515-08000			WASHER, SPRING	1	1				A	
11	F2300-08000			NUT	1	1				A	


65-01-02 PUMP ASSY INJECTION
(FOR Y262IR)



- 79 -

610337-01

65-01-03 PUMP ASSY INJECTION
(FOR Y362IR)




- 81 -


610337-01

65-01-04 INJECTION PUMP BODY ASSY


- 82 -




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1	*			BODY ASSY, INJECTION	1	1					
1 01	19011-05060			HOUSING KIT, INJ PUMP	1	1					
1 02	94904-30010			BOLT, STUD	3	3					
1 03	09013-10330			HOLDER, DELIVERY	4	4					
1 04	09013-60020			SPRING, DELIVERY	4	4					A
1 05	09013-70100			GASKET, DELIVERY	4	4					A
1 06	09014-00660			VALVE SUB ASSY, I/P	4	4					
1 07	09015-03830			ELEMENT SUB ASSY, I/P	4	4					
1 08	09015-60010			PINION, PLUNGER	4	4					
1 09	09015-70010			SCREW, PLUNGER	4	4					A
1 10	09016-10330			SLEEVE, CONTROL	4	4					
1 11	09016-30191			SEAT, UPPER SPRING	4	4					
1 12	09016-40090			SPRING, PUMP PLUNGER	4	4					A
1 13	09016-50160			SEAT, LOWER SPRING	4	4					
1 14	09017-00070			TAPPET SUB ASSY, I/P	4	4					
1 15	09018-90090			PLUG, INJECTION PUMP	4	4					A
1 16	09019-10082			CAMSHAFT, I/P	1	1					
1 17	09019-30020			RING, ADJUSTING	2	2					
1 18	09019-40010			PLATE CAMSHAFT SHIM T=0.10	AR	AR					A
	09019-40020			PLATE CAMSHAFT SHIM T=0.12	AR	AR					A
	09019-40030			PLATE CAMSHAFT SHIM T=0.14	AR	AR					A
	09019-40040			PLATE CAMSHAFT SHIM T=0.16	AR	AR					A
	09019-40050			PLATE CAMSHAFT SHIM T=0.18	AR	AR					A
	09019-40060			PLATE CAMSHAFT SHIM T=0.50	AR	AR					A
	09019-40110			PLATE CAMSHAFT SHIM T=0.30	AR	AR					A
	09019-40140			PLATE CAMSHAFT SHIM T=1.00	AR	AR					A
	09019-40150			PLATE CAMSHAFT SHIM T=1.50	AR	AR					A
	09019-40290			PLATE CAMSHAFT SHIM T=2.00	AR	AR					A
	09019-40400			PLATE CAMSHAFT SHIM T=0.03	AR	AR					A
1 19	09020-10300			COVER, BEARING	1	1					
1 20	09020-60160			GASKET, BEARING COVER	1	1					A
1 21	09021-20020			RACK, CONTROL	1	1					
1 22	09021-50060			SCREW, RACK GUIDE	1	1					A
1 23	09022-20070			WASHER, UNION	2	2					A
1 24	09023-00050			PLATE SET, LOCK	2	2					
1 25	94914-02570			O-RING	4	4					A
1 26	09025-10010			WASHER, DRAIN UNION	2	2					A
1 27	09027-01460			COVER SUB ASSY, I/P	1	1					
1 28	09024-30030			PACKING, AIR BLEEDER	2	2					A
1 29	09027-60030			SCREW, HEXAGON	2	2					A
1 30	09027-50182			COVER, PLATE	1	1					
1 31	09027-20210			GASKET, I/P	1	1					A
1 32	09031-10010			PLATE, TAPPET SHIM T=0.60	AR	AR					A
	09031-10020			PLATE, TAPPET SHIM T=0.70	AR	AR					A
	09031-10030			PLATE, TAPPET SHIM T=0.80	AR	AR					A
	09031-10040			PLATE, TAPPET SHIM T=0.90	AR	AR					A
	09031-10050			PLATE, TAPPET SHIM T=1.00	AR	AR					A
	09031-10060			PLATE, TAPPET SHIM T=1.10	AR	AR					A
	09031-10070			PLATE, TAPPET SHIM T=1.20	AR	AR					A
	09031-10080			PLATE, TAPPET SHIM T=1.30	AR	AR					A



REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1 32	09031-10090			PLATE, TAPPET SHIM	T=1.40	AR	AR			A	
	09031-10100			PLATE, TAPPET SHIM	T=0.10	AR	AR			A	
	09031-10110			PLATE, TAPPET SHIM	T=0.20	AR	AR			A	
	09031-10120			PLATE, TAPPET SHIM	T=0.30	AR	AR			A	
	09031-10130			PLATE, TAPPET SHIM	T=0.40	AR	AR			A	
	09031-10140			PLATE, TAPPET SHIM	T=0.50	AR	AR			A	
	09031-10150			PLATE, TAPPET SHIM	T=0.15	AR	AR			A	
	09031-10290			PLATE, TAPPET SHIM	T=0.13	AR	AR			A	
1 33	90160-06051			NUT, HEXAGON		3	3			A	
1 34	90258-06001			WASHER, SPRING		3	3			A	
1 35	94904-71360			BOLT, W/WASHER		4	4			A	
1 36	94910-10120			BEARING, ROLLER		2	2			A	
1 37	09024-00010			BLEEDER SUB ASSY, AIR		1	1				
1 38	09024-10010			WASHER, NIPPLE		1	1			A	
1 39	09024-20010			NIPPLE, AIR BLEEDER		1	1				
1 40	09024-30030			PACKING, AIR BLEEDER		1	1			A	
1 41	09024-40010			SCREW, AIR BLEEDER		1	1			A	
1 42	94914-00380			O-RING		1	1			A	
1 43	94918-00060			SCREW, HOLLOW		1	1			A	
1 44	94918-00310			SCREW, HOLLOW		1	1			A	




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1	*			GOVERNOR ASSY	1	•					
1 01	09081-00660			HOUSING, GOVERNOR	1	•					
1 02	09087-80030			PLATE	1	•					
1 03	09101-11670			COVER, GOVERNOR	1	•					
1 04	09101-40090			PIN, STOP	1	•					
1 05	09102-40031			SCREW, ADJUSTING	1	•				A	
1 06	09103-10151			NUT, CAP	1	•				A	
1 07	09100-60150			SCREW, ADJUSTING	1	•					
1 08	09094-40310			BUSHING	1	•					
1 09	09090-10150			LEVER, TENSION	1	•					
1 10	09093-00041			LEVER ASSY, CONTROL	1	•					
1 11	09098-90010			SHAFT, LEVER SUPPORT	1	•					
1 12	09099-10010			PLUG, SCREW	2	•				A	
1 13	90400-02101			PIN, SPLIT	1	•				A	
1 14	94805-30051			NUT, HEXAGON	1	•				A	
1 15	09056-00160			CAPSULE, FULL STOP	1	•					
1 16	09092-30060			NUT, ADAPTER LOCK	1	•				A	
1 17	09097-00170			SHACKLE ASSY	1	•					
1 18	94910-00010			BEARING, BALL	1	•				A	
1 19	94913-00050			KEY, WOODRUFF	1	•					
1 20	09084-00660			FLYWEIGHT ASSY	1	•				A	
1 21	94901-50500			WASHER, SPRING	1	•				A	
1 22	09084-40010			NUT, ROUND	1	•				A	
1 23	09086-10010			SLEEVE, GOVERNOR	1	•					
1 24	94901-34060			WASHER, PLATE	AR	•				A	
	94901-34070			WASHER, PLATE	AR	•				A	
	94901-34080			WASHER, PLATE	AR	•				A	
	94901-34090			WASHER, PLATE	AR	•				A	
	94901-34100			WASHER, PLATE	AR	•				A	
1 25	09088-00140			LEVER ASSY, SWIVELING	1	•					
1 26	09089-20080			BUSHING, LEVER	2	•					
1 27	90801-20160			O-RING	2	•				A	
1 28	94907-10090			WASHER, SNAP	2	•				A	
1 29	09099-20420			SPRING, CONTROL	1	•				A	
1 30	09099-30010			SPRING, START	1	•				A	
1 31	94904-71760			BOLT, W/WASHER	4	•				A	
1 32	94904-71750			BOLT, W/WASHER	2	•				A	
1 33	94915-00210			SEAL, OIL	1	•				A	
1 34	09107-11930			LEVER, ADJUSTING	1	•					
1 35	94904-71190			BOLT, W/WASHER	1	•				A	
1 36	09109-40060			CAP, LEVER	1	•					
1 37	09109-01160			LEVER SUB ASSY, STOP	1	•					
1 38	09105-00491			PLATE SUB ASSY, COVER	1	•					
1 39	94904-32250			BOLT, STUD	2	•					
1 40	91418-06161			BOLT, W/WASHER	1	•				A	
1 41	09116-70050			PLUG, SCREW	1	•				A	
1 42	09024-10010			WASHER, NIPPLE	2	•				A	
1 43	09103-10030			NUT, CAP	1	•					
1 44	94901-81550			WASHER, COPPER PLATE	1	•				A	
1 45	94906-21270			PACKING	1	•				A	




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1 46	09103-80040			SPRING,PRESSURE	1	•				A	
1 47	94914-00130			O-RING	1	•				A	
1 48	09101-60360			BUSHING,BEARING	1	•					
1 49	09104-30010			COVER,SPRING	1	•					
1 50	09103-80050			SPRING,PRESSURE	1	•				A	
1 51	09103-50240			SHAFT,GOVERNOR	1	•					
1 52	09103-60010			CUP,SPRING	1	•					
1 53	09103-40161			LEVER,SUPPORT	1	•					
1 54	09103-30030			PLATE,CAP	1	•					
1 55	09103-80030			SPRING,PRESSURE	1	•				A	
1 56	94913-00030			KEY,WOODRUFF	1	•					
1 57	09082-30460			GASKET	1	•				A	
1 58	09082-30420			GASKET	1	•				A	
1 59	94905-03390			NUT,HEXAGON	1	•				A	
1 60	94901-81020			WASHER,COPPER PLATE	2	•				A	
1 61	90801-10120			O-RING	1	•				A	
1 62	94904-72701			BOLT,W/WASHER	2	•				A	
1 63	09102-40260			SCREW,ADJUSTING	1	•				A	
1 64	90190-08051			NUT,HEXAGON	1	•				A	


65-01-06 GOVERNOR ASSY(FOR Y362IR)




REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1	*			GOVERNOR ASSY	•	1					
1 01	09081-00660		A	HOUSING, GOVERNOR	•	1					V
1 02	09087-80030		A	PLATE	•	1					V
1 03	09102-40260		A	SCREW, ADJUSTING	•	1				A	V
1 04	09101-11670		A	COVER, GOVERNOR	•	1					V
1 05	09101-40090		A	PIN, STOP	•	1					V
1 06	09102-40031		A	SCREW, ADJUSTING	•	1				A	V
1 07	09103-10151		A	NUT, CAP	•	1				A	V
1 08	09100-60150		A	SCREW, STROKE ADJUST	•	1				A	V
1 09	09094-40310		A	BUSHING	•	1					V
1 10	09090-10150		A	LEVER, TENSION	•	1					V
1 11	09093-00041		A	LEVER ASSY, CONTROL	•	1					V
1 12	09098-90010		A	SHAFT, LEVER SUPPORT	•	1					V
1 13	09099-10010		A	PLUG, SCREW	•	2				A	V
1 14	90400-02101		A	PIN, SPLIT	•	1				A	V
1 15	90190-08051		A	NUT, HEXAGON	•	1				A	V
1 16	94805-30051		A	NUT, HEXAGON, W/HOLE	•	1				A	V
1 17	09056-00160		A	CAPSULE, FULL STOP	•	1					V
1 18	09092-30060		A	NUT, ADAPTER LOCK	•	1				A	V
1 19	09097-00170		A	SHACKLE ASSY	•	1					V
1 20	94910-00010		A	BEARING, BALL	•	1				A	V
1 21	94913-00050		A	KEY, WOODRUFF	•	1					V
1 22	09084-00660		A	FLYWEIGHT ASSY	•	1					V
1 23	94901-50500		A	WASHER, SPRING	•	1				A	V
1 24	09084-40010		A	NUT, ROUND	•	1				A	V
1 25	09086-10010		A	SLEEVE, GOVERNOR	•	1					V
1 26	94901-34060		A	WASHER, PLATE	•	AR				A	V
	94901-34070		A	WASHER, PLATE	•	AR				A	V
	94901-34080		A	WASHER, PLATE	•	AR				A	V
	94901-34090		A	WASHER, PLATE	•	AR				A	V
	94901-34100		A	WASHER, PLATE	•	AR				A	V
1 27	09088-00140		A	LEVER, SWIVELING	•	1					V
1 28	09089-20080		A	BUSHING, LEVER	•	2					V
1 29	90801-20160		A	O-RING	•	2				A	V
1 30	94907-10090		A	WASHER, SNAP	•	2				A	V
1 31	09099-20420		A	SPRING, SPEED CONTROL	•	1				A	V
1 32	09099-30010		A	SPRING, START	•	1				A	V
1 33	09091-00720		A	ADAPTER ASSY	•	1					V
1 34	09091-10010		A	SCREW, ADAPTER	•	1				A	V
1 35	09091-81220		A	SPRING, GOVERNOR	•	1				A	V
1 36	09091-90010		A	ADAPTER	•	1					V
1 37	09089-40010		A	E-RING	•	1				A	V
1 38	94901-33880		A	WASHER, PLATE	•	AR				A	V
	94901-34020		A	WASHER, PLATE	•	AR				A	V
	94901-34030		A	WASHER, PLATE	•	AR				A	V
	94901-34040		A	WASHER, PLATE	•	AR				A	V
1 39	09092-30011		A	NUT, ADAPTER LOCK	•	1				A	V
1 40	94904-71760		A	BOLT, W/WASHER	•	4				A	V
1 41	94904-71750		A	BOLT, W/WASHER	•	2				A	V
1 42	94915-00210		A	SEAL, OIL	•	1				A	V



REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y262IR	Y362IR		FROM@-	-@UPTO		
1 43	09107-11930		A	LEVER, ADJUSTING	•	1					V
1 44	94904-71190		A	BOLT, W/WASHER	•	1				A	V
1 45	09109-40060		A	CAP, LEVER	•	1					V
1 46	09109-01160		A	LEVER, SUB ASSY, STOP	•	1					V
1 47	94904-32250		A	BOLT, STUD	•	2					V
1 48	09105-00491		A	PLATE, SUB ASSY, COVER	•	1					V
1 49	94904-72701		A	BOLT, W/WASHER	•	2				A	V
1 50	91418-06161		A	BOLT, W/WASHER	•	1				A	V
1 51	09116-70050		A	PLUG, SCREW	•	1				A	V
1 52	09024-10010		A	WASHER, NIPPLE	•	2				A	V
1 53	09103-10030		A	NUT, CAP	•	1					V
1 54	94901-81550		A	WASHER, COPPER PLATE	•	1				A	V
1 55	94906-21270		A	PACKING, RUBBER PLATE	•	1				A	V
1 56	09103-80040		A	SPRING, PRESSURE	•	1				A	V
1 57	94914-00130		A	O-RING	•	1				A	V
1 58	09101-60360		A	BUSHING, BEARING	•	1					V
1 59	09104-30010		A	COVER, SPRING	•	1					V
1 60	09103-80050		A	SPRING, PRESSURE	•	1				A	V
1 61	09103-50240		A	SHAFT, MECHANICAL GOV	•	1					V
1 62	09103-60010		A	CUP, SPRING	•	1					V
1 63	09103-40161		A	LEVER, SUPPORT	•	1					V
1 64	09103-30030		A	PLATE, CAP	•	1					V
1 65	09103-80030		A	SPRING, PRESSURE	•	1				A	V
1 66	94913-00030		A	KEY, WOODRUFF	•	1					V
1 67	09082-30460		A	GASKET	•	1				A	V
1 68	09082-30420		A	GASKET	•	1				A	V
1 69	94905-03390		A	NUT, HEXAGON	•	1				A	V
1 70	94901-81020		A	WASHER, COPPER PLATE	•	2				A	V
1 71	90801-10120		A	O-RING	•	1				A	V





REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	34461-09050			PUMP ASSY, FEED	1	1					
1 01	09212-00161			HOUSING SUB ASSY	1	1				A	
1 02	09216-80150			ROD, PUSH	1	1					
1 03	09212-10011			VALVE, CHECK	2	2					
1 04	09212-40010			SPRING, VALVE	2	2				A	
1 05	09212-50010			GASKET, PLUG	2	2				A	
1 06	09212-70010			SUPPORT, VALVE	1	1					
1 07	09213-00220			PUMP, PRIMING	1	1					
1 08	09222-30070			SCREW, HOLLOW	1	1				A	
1 09	09022-20070			WASHER, SEALING	4	4				A	
1 10	09217-40030			TAPPET, FEED PUMP	1	1					
1 11	09217-60010			ROLLER, TAPPET	1	1				A	
1 12	09217-80010			PIN, ROLLER	1	1					
1 13	09217-90050			BLOCK, SLIDING	2	2					
1 14	94907-20940			RING, SNAP	1	1				A	
1 15	09218-20020			SPRING, PISTON	1	1				A	
1 16	94901-81240			WASHER	1	1				A	
1 17	09218-40021			PLUG, CHAMBER	1	1				A	
1 18	09222-00040			FILTER, FUEL	1	1				A	
1 19	09217-10011			PISTON	1	1				A	
1 20	94918-00310			SCREW, HOLLOW	1	1				A	
1 21	94915-02700			SEAL, OIL	1	1				A	



PART WITHOUT REF. NO. WILL NOT BE SUPPLIED.


REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A66-10101			STARTER ASSY	1	1					
1 01	M641X-B1571			BRACKET ASSY,FRONT	1	1					
1 02	M690X-00572			BEARING SET	1	1				A	
1 03	M357X-91874			SHAFT ASSY,CLUTCH	1	1					
1 04	M357X-66185			SHAFT ASSY,GEAR	1	1					
1 05	M982X-38871			WASHER SET	1	1				A	
1 06	M135X-01581			GEAR ASSY, INTERNAL	1	1					
1 07	M191X-67685			CLUTCH,OVER RUNNING	1	1					
1 08	M230X-00671			GEAR ASSY	4	4					
1 09	M863X-08673			LEVER ASSY	1	1					
1 10	M605X-96571			PINION SET	1	1					
1 11	M385X-03771			STOPPER SET	1	1					
1 12	M372X-02871			SWITCH ASSY	1	1					
1 13	M414X-04875			SCREW SET	1	1				A	
1 14	S409S-00008			BALL	1	1				A	
1 15	M578X-29171			PACKING SET	1	1				A	
1 16	M106X-43571			ARMATURE SET	1	1					
1 17	S930P-29970			BEARING	1	1				A	
1 18	M800X-73771			YOKE ASSY	1	1					
1 19	M649X-20471			HOLDER ASSY,BRUSH	1	1					
1 20	M391X-04371			SPRING,BRUSH	4	4				A	
1 21	M642X-35671			BRACKET ASSY,REAR	1	1					
1 22	M901X-00371			BOLT SET	1	1				A	
1 23	M648X-40771			BRUSH	2	2				A	






REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A68-01201	3	1	BRACKET, ALTERNATOR	1	1		@179577		A	V
2	MF240053			BOLT, W/WASHER	2	•					
3	32A13-02700			BOLT, FLANGE	2	2					
4	F1035-10040			BOLT	1	1					
5	F2515-10000			WASHER, SPRING	1	1				A	
6	32A68-01500			PLATE, ADJUSTING	1	1				A	
7	MF140026			BOLT, FLANGE	1	1				A	
	MD001521			WASHER	1	1				A	






68-00-02 ALTERNATOR(12V-50A)




PART WITHOUT REF. NO. WILL NOT BE SUPPLIED.


REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A68-00302			ALTERNATOR ASSY	1	1					
1 01	A981X-20771			NUT SET	1	1				A	
1 02	A628T-63370			PULLET ASSY	1	1				A	
1 03	A414X-19271			BOLT SET	1	1				A	
1 04	A640X-67070			BRACKET ASSY,FRONT	1	1					
1 05	A414X-21271			SCREW SET	1	1				A	
1 06	A930X-94570			BEARING,FRONT	1	1				A	
1 07	A880X-83770			ROTOR ASSY	1	1					
1 08	S930P-63670			BEARING,REAR	1	1				A	
1 09	A383X-56570			STATOR ASSY	1	1					
1 10	A642X-A9970			BRACKET ASSY,REAR	1	1					
1 11	A866X-44682			REGULATOR SET	1	1					
1 12	A647X-50170			BRUSH SET	2	2				A	
1 13	A860T-40670			RECTIFIER ASSY	1	1					
1 14	A529X-07871			NUT SET	1	1				A	







REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION		MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y2621R	Y3621R		FROM@-	-@UPTO		
1	32A94-00040	3	1	GASKET KIT,OVERHAUL	EO-00	1	•		@188693			V
	32A94-10040			GASKET KIT,OVERHAUL	EO-01	1	1					
1 01	F3150-02000			O-RING		3	3					
1 02	F4202-14000			GASKET	NOT SHOWN	1	1					
1 03	34340-00700			GASKET		1	1					
1 04	MD068355			GASKET,FUEL RETURN		4	4					A
1 05	MD070717			GASKET,HOLDER		4	4					
1 07	05946-00801			WASHER,SEALING		1	1					
1 08	05946-01401			WASHER,SEALING		10	10					
1 09	32A35-00600			O-RING		1	1					
1 10	06016-13140			O-RING		2	2					A
1 11	30636-25901			GASKET		2	2					
1 12	30661-51300			GASKET,INJ PUMP		1	1					
1 13	32A01-02204			GASKET,CYLINDER HEAD		1	1					
1 14	32A01-02501			GASKET,HEAD REAR		1	1					
1 15	32A04-02801			SEAL,VALVE STEM		8	8					A
1 16	32A04-13200			GASKET,ROCKER COVER		1	1					
1 17	32A07-04100			GASKET,FRONT PLATE		1	1					
	32A07-04500			GASKET,FRONT PLATE	EO-01 NOT SHOWN	1	1					
1 18	32A07-11700			SEAL,SIDE		2	2					
1 19	32A07-14201			GASKET,REAR		1	1					A
1 20	32A11-00200			GASKET,GEAR CASE		1	1					
	32A11-10700			GASKET,GEAR CASE	EO-01 NOT SHOWN	1	1					
1 21	32A30-00201			GASKET,INLET MANF		1	1					
1 22	32A32-00200			GASKET,EXHAUST		1	1					
1 23	32A32-01400			GASKET,EXHAUST		1	1					A
1 24	32A39-11200			GASKET,SIDE COVER	EO-00	1	•					
	32A39-21200			GASKET,SIDE COVER	EO-01	1	1					
1 25	32A45-00400			GASKET,PUMP COVER	EO-00	1	•					
	32A45-10400			GASKET,PUMP COVER	EO-01	1	1					
1 26	32A45-00500			GASKET,WATER PUMP	EO-00	1	•					A
	32A45-10500			GASKET,WATER PUMP	EO-01	1	1					
1 27	32A46-01400			GASKET,THERMOSTAT		1	1					
1 28	32A91-05100			GASKET,LIQUID	NOT SHOWN	1	1					
1 29	34232-00300			GASKET,EXHAUST	NOT SHOWN	1	1					
1 30	34330-04300			GASKET,AIR HEATER		1	1					A
1 31	34446-05300			GASKET,THERMO CASE	EO-00 NOT SHOWN	1	•					
	32A46-01800			GASKET,THERMO CASE	EO-01	1	1					
1 32	F3156-02500			O-RING	NOT SHOWN	2	2					
1 33	F4202-08000			GASKET	NOT SHOWN	4	4					
1 34	F4202-10000			GASKET	NOT SHOWN	2	2					A
1 35	F4202-18000			GASKET	NOT SHOWN	2	2					
1 36	MM432045			GASKET,NOZZLE	NOT SHOWN	4	4					
1 37	MM433993			O-RING	NOT SHOWN	1	1					
1 38	05507-10110			O-RING	NOT SHOWN	1	1					
1 39	05946-00601			WASHER,SEALING	NOT SHOWN	8	8					A
1 40	05946-01001			WASHER,SEALING	NOT SHOWN	2	2					
1 41	05946-01201			WASHER,SEALING	NOT SHOWN	2	2					
1 42	06016-13075			O-RING	NOT SHOWN	1	1					
1 43	32A32-03300			GASKET	NOT SHOWN	1	1					



REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION		MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y2621R	Y3621R		FROM@-	-@UPTO		
1 44	32A39-11400			GASKET	NOT SHOWN	1	1				A	
1 45	32A90-13600			GASKET, WATER HEATER	NOT SHOWN	1	1				A	
1 46	34336-04100			GASKET, OIL PIPE	NOT SHOWN	1	1				A	
1 47	32A61-56900			GASKET	NOT SHOWN	1	1				A	

NUMERICAL PARTS INDEX

PART NO.	GRP NO.	PAGE-NO.	REF.	PART NO.	GRP NO.	PAGE-NO.	REF.	PART NO.	GRP NO.	PAGE-NO.	REF.
A383X-56570	68-00-02	103	1 09	M106X-43571	66	97	1 16	MF241251	05	11	4
A414X-19271	68-00-02	103	1 03	M135X-01581	66	97	1 06	MF241251	11	17	3
A414X-21271	68-00-02	103	1 05	M191X-67685	66	97	1 07	MF241251	35-02	43	3
A529X-07871	68-00-02	103	1 14	M230X-00671	66	97	1 08	MF241253	65-01-01	77	5
A628T-63370	68-00-02	103	1 02	M357X-66185	66	97	1 04	MF241255	04	7	8 12
A640X-67070	68-00-02	103	1 04	M357X-91874	66	97	1 03	MF241261	04-02	9	3
A642X-A9970	68-00-02	103	1 10	M372X-02871	66	97	1 12	MF241261	30	35	3
A647X-50170	68-00-02	103	1 12	M385X-03771	66	97	1 11	MF241261	48-02	65	2
A860T-40670	68-00-02	103	1 13	M391X-04371	66	97	1 20	MF241262	45	53	3
A866X-44682	68-00-02	103	1 11	M414X-04875	66	97	1 13	MF241264	11	17	6
A880X-83770	68-00-02	103	1 07	M578X-29171	66	97	1 15	MF241266	11	17	9
A930X-94570	68-00-02	103	1 06	M605X-96571	66	97	1 10	MF241266	45	53	4
A981X-20771	68-00-02	103	1 01	M641X-B1571	66	97	1 01	MF241268	46	57	4
F1035-08020	32	39	3	M642X-35671	66	97	1 21	MF241280	23	33	5
F1035-08090	30	35	4	M648X-40771	66	97	1 23	MF241282	12	19	3
F1035-10040	68-00-01	101	3	M649X-20471	66	97	1 19	MF241284	12	19	4
F1035-12035	21	31	2	M690X-00572	66	97	1 02	MF243628	61-00-01	69	7
F1805-10025	62	75	4	M800X-73771	66	97	1 18	MF243648	45-02	55	2
F1825-06012	47-00-01	59	1 04	M863X-08673	66	97	1 09	MF244826	47-00-02	61	1 04
F2015-10035	65-01-01	77	4	M901X-00371	66	97	1 22	MF407726	12	19	6
F2300-06000	87-05	105	4	M982X-38871	66	97	1 05	MF522010	04	7	8 09
F2300-08000	32	39	5	MB084014	92	107	4	MH001401	45	53	1 05
F2300-08000	65-01-01	77	11	MD000269	07	13	13	MH037084	62	75	1 05
F2300-08000	92	107	2	MD000312	12	19	11	MH037087	62	75	1 03
F2300-10000	12	19	8	MD001404	12	19	12	MM316248	01	3	6
F2320-10000	35	41	4	MD001521	68-00-01	101	7	MM316248	12	19	9
F2325-08000	04	7	8 02	MD008784	04-02	9	4	MM316248	46	57	8
F2500-06000	87-05	105	2	MD050316	13	21	1 02	MM409660	92	107	3
F2515-06000	87-05	105	3	MD050317	13	21	1 01	MM430614	61-00-01	69	6
F2515-08000	30	35	5	MD068353	61-00-01	69	2	MM430703	61-00-01	69	5
F2515-08000	65-01-01	77	10	MD068355	61-00-01	69	3	MM432045	94	109	1 36
F2515-10000	12	19	7	MD068355	94	109	1 04	MM433993	94	109	1 37
F2515-10000	35	41	5	MD070717	61-00-01	69	4	MS661140	07	13	14
F2515-10000	68-00-01	101	4	MD070717	94	109	1 05	MS661142	07	13	15
F2515-12000	21	31	3	ME910-12501	61-00-01	69	13	S409S-00008	66	97	1 14
F2846-05000	07	13	8	MF140026	68-00-01	101	6	S930P-29970	66	97	1 17
F2846-10000	20	27	1 02	MF140227	46	57	11	S930P-63670	68-00-02	103	1 08
F2846-12000	07	13	7	MF140231	45	53	1 03	04826-21200	04	7	8 08
F2850-04008	07	13	9	MF140239	46	57	4	04826-21800	07	13	3
F2870-07022	05	11	2	MF140433	46	57	5	04826-21800	07	13	3
F2870-07022	20	27	1 03	MF240049	61-00-01	69	10	04826-22000	01	3	2 01
F3150-02000	35-02	43	2	MF240051	01-02	5	4	04826-22500	01	3	2 02
F3150-02000	94	109	1 01	MF240051	13	21	2	04826-23500	07	13	2 01
F3156-02500	94	109	1 32	MF240051	39	47	3	04827-90170	07	13	16
F3202-03000	17	23	2	MF240053	01-02	5	5	05317-01600	47-00-01	59	4
F4202-08000	94	109	1 33	MF240053	35	41	3	05317-01600	47-00-02	61	4
F4202-10000	94	109	1 34	MF240053	62	75	3	05317-01700	47-00-01	59	8
F4202-14000	94	109	1 02	MF240053	68-00-01	101	2	05317-01700	47-00-02	61	8
F4202-18000	94	109	1 35	MF240054	30-02	37	3	05317-50301	46	57	7
F4440-06300	65-01-01	77	6	MF240062	46	57	5	05507-10110	94	109	1 38

NUMERICAL PARTS INDEX

PART NO.	GRP NO.	PAGE	REF. NO.	PART NO.	GRP NO.	PAGE	REF. NO.	PART NO.	GRP NO.	PAGE	REF. NO.
05605-01410	07	13	10	09024-10010	65-01-04	85	1 38	09090-10150	65-01-06	91	1 10
05660-01410	07	13	10	09024-10010	65-01-05	87	1 42	09091-00720	65-01-06	91	1 33
05910-10045	49	67	1	09024-10010	65-01-06	93	1 52	09091-10010	65-01-06	91	1 34
05946-00601	94	109	1 39	09024-20010	65-01-04	85	1 39	09091-81220	65-01-06	91	1 35
05946-00801	62	75	1 06	09024-30030	65-01-04	83	1 28	09091-90010	65-01-06	91	1 36
05946-00801	94	109	1 07	09024-30030	65-01-04	85	1 40	09092-30011	65-01-06	91	1 39
05946-01001	94	109	1 40	09024-40010	65-01-04	85	1 41	09092-30060	65-01-05	87	1 16
05946-01201	94	109	1 41	09025-10010	65-01-04	83	1 26	09092-30060	65-01-06	91	1 18
05946-01401	62	75	1 04	09027-01460	65-01-04	83	1 27	09093-00041	65-01-05	87	1 10
05946-01401	94	109	1 08	09027-20210	65-01-04	83	1 31	09093-00041	65-01-06	91	1 11
06016-13075	94	109	1 42	09027-50182	65-01-04	83	1 30	09094-40310	65-01-05	87	1 08
06016-13140	11	17	8	09027-60030	65-01-04	83	1 29	09094-40310	65-01-06	91	1 09
06016-13140	65-01-01	77	2	09031-10010	65-01-04	83	1 32	09097-00170	65-01-05	87	1 17
06016-13140	94	109	1 10	09031-10020	65-01-04	83	1 32	09097-00170	65-01-06	91	1 19
09001-80081	65-01-02	79	1 03	09031-10030	65-01-04	83	1 32	09098-90010	65-01-05	87	1 11
09001-80081	65-01-03	81	1 03	09031-10040	65-01-04	83	1 32	09098-90010	65-01-06	91	1 12
09013-10330	65-01-04	83	1 03	09031-10050	65-01-04	83	1 32	09099-10010	65-01-05	87	1 12
09013-60020	65-01-04	83	1 04	09031-10060	65-01-04	83	1 32	09099-10010	65-01-06	91	1 13
09013-70100	65-01-04	83	1 05	09031-10070	65-01-04	83	1 32	09099-20420	65-01-05	87	1 29
09014-00660	65-01-04	83	1 06	09031-10080	65-01-04	83	1 32	09099-20420	65-01-06	91	1 31
09015-03830	65-01-04	83	1 07	09031-10090	65-01-04	85	1 32	09099-30010	65-01-05	87	1 30
09015-60010	65-01-04	83	1 08	09031-10100	65-01-04	85	1 32	09099-30010	65-01-06	91	1 32
09015-70010	65-01-04	83	1 09	09031-10110	65-01-04	85	1 32	09100-60150	65-01-05	87	1 07
09016-10330	65-01-04	83	1 10	09031-10120	65-01-04	85	1 32	09100-60150	65-01-06	91	1 08
09016-30191	65-01-04	83	1 11	09031-10130	65-01-04	85	1 32	09101-11670	65-01-05	87	1 03
09016-40090	65-01-04	83	1 12	09031-10140	65-01-04	85	1 32	09101-11670	65-01-06	91	1 04
09016-50160	65-01-04	83	1 13	09031-10150	65-01-04	85	1 32	09101-40090	65-01-05	87	1 04
09017-00070	65-01-04	83	1 14	09031-10290	65-01-04	85	1 32	09101-40090	65-01-06	91	1 05
09018-90090	65-01-04	83	1 15	09056-00160	65-01-05	87	1 15	09101-60360	65-01-05	89	1 48
09019-10082	65-01-04	83	1 16	09056-00160	65-01-06	91	1 17	09101-60360	65-01-06	93	1 58
09019-30020	65-01-04	83	1 17	09081-00660	65-01-05	87	1 01	09102-40031	65-01-05	87	1 05
09019-40010	65-01-04	83	1 18	09081-00660	65-01-06	91	1 01	09102-40031	65-01-06	91	1 06
09019-40020	65-01-04	83	1 18	09082-30420	65-01-05	89	1 58	09102-40260	65-01-05	89	1 63
09019-40030	65-01-04	83	1 18	09082-30420	65-01-06	93	1 68	09102-40260	65-01-06	91	1 03
09019-40040	65-01-04	83	1 18	09082-30460	65-01-05	89	1 57	09103-10030	65-01-05	87	1 43
09019-40050	65-01-04	83	1 18	09082-30460	65-01-06	93	1 67	09103-10030	65-01-06	93	1 53
09019-40060	65-01-04	83	1 18	09084-00660	65-01-05	87	1 20	09103-10151	65-01-05	87	1 06
09019-40110	65-01-04	83	1 18	09084-00660	65-01-06	91	1 22	09103-10151	65-01-06	91	1 07
09019-40140	65-01-04	83	1 18	09084-40010	65-01-05	87	1 22	09103-30030	65-01-05	89	1 54
09019-40150	65-01-04	83	1 18	09084-40010	65-01-06	91	1 24	09103-30030	65-01-06	93	1 64
09019-40290	65-01-04	83	1 18	09086-10010	65-01-05	87	1 23	09103-40161	65-01-05	89	1 53
09019-40400	65-01-04	83	1 18	09086-10010	65-01-06	91	1 25	09103-40161	65-01-06	93	1 63
09020-10300	65-01-04	83	1 19	09087-80030	65-01-05	87	1 02	09103-50240	65-01-05	89	1 51
09020-60160	65-01-04	83	1 20	09087-80030	65-01-06	91	1 02	09103-50240	65-01-06	93	1 61
09021-20020	65-01-04	83	1 21	09088-00140	65-01-05	87	1 25	09103-60010	65-01-05	89	1 52
09021-50060	65-01-04	83	1 22	09088-00140	65-01-06	91	1 27	09103-60010	65-01-06	93	1 62
09022-20070	65-01-04	83	1 23	09089-20080	65-01-05	87	1 26	09103-80030	65-01-05	89	1 55
09022-20070	65-01-07	95	1 09	09089-20080	65-01-06	91	1 28	09103-80030	65-01-06	93	1 65
09023-00050	65-01-04	83	1 24	09089-40010	65-01-06	91	1 37	09103-80040	65-01-05	89	1 46
09024-00010	65-01-04	85	1 37	09090-10150	65-01-05	87	1 09	09103-80040	65-01-06	93	1 56

NUMERICAL PARTS INDEX

PART NO.	GRP NO.	PAGE	REF.	PART NO.	GRP NO.	PAGE	REF.	PART NO.	GRP NO.	PAGE	REF.
		GE	-NO.			GE	-NO.			GE	-NO.
09103-80050	65-01-05	89	1 50	09317-51820	61-00-02	71	1 07	32A01-02204	94	109	1 13
09103-80050	65-01-06	93	1 60	09317-51830	61-00-02	71	1 07	32A01-02501	01-02	5	3
09104-30010	65-01-05	89	1 49	09317-51840	61-00-02	71	1 07	32A01-02501	94	109	1 14
09104-30010	65-01-06	93	1 59	09317-51850	61-00-02	71	1 07	32A01-02700	01-02	5	1
09105-00491	65-01-05	87	1 38	09317-51860	61-00-02	71	1 07	32A01-02800	01-02	5	2
09105-00491	65-01-06	93	1 48	09317-51870	61-00-02	71	1 07	32A01-03100	01	3	2 05
09107-11930	65-01-05	87	1 34	09317-51880	61-00-02	71	1 07	32A01-03200	01	3	2 06
09107-11930	65-01-06	93	1 43	09317-51890	61-00-02	71	1 07	32A01-11020	01	3	1
09109-01160	65-01-05	87	1 37	09317-51900	61-00-02	71	1 07	32A01-21020	01	3	1
09109-01160	65-01-06	93	1 46	09317-51910	61-00-02	71	1 07	32A03-01100	01	3	2 07
09109-40060	65-01-05	87	1 36	09317-51920	61-00-02	71	1 07	32A04-02401	04	7	8 04
09109-40060	65-01-06	93	1 45	09317-51930	61-00-02	71	1 07	32A04-02801	04	7	7
09116-70050	65-01-05	87	1 41	09317-51940	61-00-02	71	1 07	32A04-02801	94	109	1 15
09116-70050	65-01-06	93	1 51	09317-51950	61-00-02	71	1 07	32A04-04011	04	7	8 06
09212-00161	65-01-07	95	1 01	09317-51960	61-00-02	71	1 07	32A04-04701	04	7	8 10
09212-10011	65-01-07	95	1 03	09317-51970	61-00-02	71	1 07	32A04-04801	04	7	8 11
09212-40010	65-01-07	95	1 04	09317-51980	61-00-02	71	1 07	32A04-09100	04-02	9	1 01
09212-50010	65-01-07	95	1 05	09317-51990	61-00-02	71	1 07	32A04-09100	30	35	1 01
09212-70010	65-01-07	95	1 06	09317-52000	61-00-02	71	1 07	32A04-13012	04-02	9	1
09213-00220	65-01-07	95	1 07	09317-52010	61-00-02	71	1 07	32A04-13200	04-02	9	2
09216-80150	65-01-07	95	1 02	09317-52020	61-00-02	71	1 07	32A04-13200	94	109	1 16
09217-10011	65-01-07	95	1 19	09317-52030	61-00-02	71	1 07	32A04-20100	04	7	1
09217-40030	65-01-07	95	1 10	09317-52040	61-00-02	71	1 07	32A04-21100	04	7	2
09217-60010	65-01-07	95	1 11	09317-52050	61-00-02	71	1 07	32A04-22010	04	7	8 01
09217-80010	65-01-07	95	1 12	09317-52060	61-00-02	71	1 07	32A05-00101	05	11	1
09217-90050	65-01-07	95	1 13	09317-52070	61-00-02	71	1 07	32A05-02101	05	11	5
09218-20020	65-01-07	95	1 15	09317-52080	61-00-02	71	1 07	32A05-13100	05	11	6
09218-40021	65-01-07	95	1 17	09317-52090	61-00-02	71	1 07	32A07-01501	07	13	6
09222-00040	65-01-07	95	1 18	19011-05060	65-01-04	83	1 01	32A07-02600	07	13	2 04
09222-30070	65-01-07	95	1 08	30405-31403	05	11	3	32A07-04100	11	17	2
09311-05480	61-00-02	71	1 02	30604-21402	04	7	3	32A07-04100	94	109	1 17
09312-10380	61-00-02	71	1 03	30604-31601	04	7	4	32A07-04500	94	109	1 17
09312-70360	61-00-02	71	1 04	30619-10501	19	25	1 01	32A07-11700	07	13	12
09316-41351	61-00-02	71	1 05	30636-25901	01	3	7	32A07-11700	94	109	1 18
09317-40070	61-00-02	71	1 06	30636-25901	12	19	10	32A07-14201	12	19	2
09317-51670	61-00-02	71	1 07	30636-25901	46	57	9	32A07-14201	94	109	1 19
09317-51680	61-00-02	71	1 07	30636-25901	94	109	1 11	32A07-21010	07	13	1
09317-51690	61-00-02	71	1 07	30661-50802	61-00-01	69	11	32A07-31010	07	13	1
09317-51700	61-00-02	71	1 07	30661-51300	65-01-01	77	3	32A07-41010	07	13	1
09317-51710	61-00-02	71	1 07	30661-51300	94	109	1 12	32A09-00010	09	15	1
09317-51720	61-00-02	71	1 07	30L93-08100	92	107	5	32A09-00020	09	15	2
09317-51730	61-00-02	71	1 07	31304-11700	04	7	6	32A09-00030	09	15	3
09317-51740	61-00-02	71	1 07	31345-12100	48	63	1	32A09-00040	09	15	4
09317-51750	61-00-02	71	1 07	31A47-03100	47-00-01	59	5	32A11-00105	11	17	4
09317-51760	61-00-02	71	1 07	31A47-03100	47-00-02	61	5	32A11-00200	11	17	5
09317-51770	61-00-02	71	1 07	31A47-03500	47-00-01	59	6	32A11-00200	94	109	1 20
09317-51780	61-00-02	71	1 07	31A47-03500	47-00-02	61	6	32A11-01100	11	17	7
09317-51790	61-00-02	71	1 07	32A01-01400	01	3	4	32A11-03100	11	17	1
09317-51800	61-00-02	71	1 07	32A01-01600	01	3	2 04	32A11-04010	11	17	10
09317-51810	61-00-02	71	1 07	32A01-02204	01	3	5	32A11-10100	11	17	4

NUMERICAL PARTS INDEX

PART NO.	GRP NO.	PAGE	REF.	PART NO.	GRP NO.	PAGE	REF.	PART NO.	GRP NO.	PAGE	REF.
GE-NO.	GE-NO.	GE-NO.	GE-NO.	GE-NO.	GE-NO.	GE-NO.	GE-NO.	GE-NO.	GE-NO.	GE-NO.	GE-NO.
32A11-10700	94	109	1 20	32A39-11200	39	47	2	32A61-01201	65-01-01	77	1
32A11-13100	11	17	1	32A39-11200	94	109	1 24	32A61-03700	61-00-01	69	9
32A11-23100	11	17	1	32A39-11400	94	111	1 44	32A61-03901	61-00-01	69	14
32A13-00011	13	21	1	32A39-21200	39	47	2	32A61-04100	61-00-01	69	8
32A13-02700	65-01-01	77	9	32A39-21200	94	109	1 24	32A61-04700	61-00-01	69	12
32A13-02700	68-00-01	101	2	32A40-00100	40	49	1	32A61-56900	94	111	1 47
32A17-02010	17	23	6	32A40-00400	40	49	1	32A61-59100	61-00-01	69	19
32A17-02020	17	23	7	32A40-01100	40	49	2	32A61-59200	61-00-01	69	20
32A17-02030	17	23	8	32A40-01101	40	49	2	32A61-59300	61-00-01	69	21
32A17-08300	17	23	1	32A40-10100	40	49	1	32A62-30201	62	75	2
32A17-10100	17	23	3	32A42-05100	13	21	3	32A65-01730	65-01-02	79	1
32A17-10200	17	23	4	32A43-01700	43	51	1	32A65-01740	65-01-03	81	1
32A17-10300	17	23	5	32A45-00300	45	53	1 01	32A66-03100	66-02	99	1
32A19-00012	19	25	1	32A45-00400	45	53	1 02	32A66-03101	66-02	99	1
32A19-00400	19	25	1 02	32A45-00400	94	109	1 25	32A66-04101	66-02	99	2
32A19-00501	19	25	1 03	32A45-00500	45	53	2	32A66-10101	66	97	1
32A19-09011	19	25	2	32A45-00500	94	109	1 26	32A68-00302	68-00-02	103	1
32A19-09021	19	25	3	32A45-01600	45	53	1 04	32A68-01201	68-00-01	101	1
32A19-09031	19	25	4	32A45-02100	45-02	55	1	32A68-01500	68-00-01	101	5
32A19-09041	19	25	5	32A45-10030	45	53	1	32A87-05300	87-05	105	6
32A20-00014	20	27	1	32A45-10031	45	53	1	32A87-05400	87-05	105	7
32A20-02101	20-02	29	1	32A45-10400	45	53	1 02	32A87-05500	87-05	105	5 02
32A20-02901	20	27	1 01	32A45-10400	94	109	1 25	32A87-05900	87-05	105	5 01
32A20-02902	20	27	1 01	32A45-10500	45	53	2	32A87-07050	87-05	105	5
32A21-00051	21	31	1	32A45-10500	94	109	1 26	32A87-07060	87-05	105	5
32A21-00900	21	31	1 01	32A46-01101	46	57	12	32A90-13600	94	111	1 45
32A23-00101	20	27	1 05	32A46-01400	46	57	10	32A91-05100	94	109	1 28
32A23-01100	23	33	1	32A46-01400	94	109	1 27	32A94-00040	94	109	1
32A23-01101	23	33	1	32A46-01800	46	57	3	32A94-10040	94	109	1
32A23-03010	23	33	3	32A46-01800	94	109	1 31	32B09-08101	09	15	5
32A23-03200	23	33	3 02	32A46-02050	46	57	2	32B09-08201	09	15	6
32A23-03500	07	13	11	32A46-02100	46	57	1	32B09-08301	09	15	7
32A23-12301	23	33	2	32A46-02600	46	57	6	32B12-20103	12	19	1
32A30-00201	30	35	2	32A47-02700	47-00-01	59	2	32B12-20104	12	19	1
32A30-00201	94	109	1 21	32A47-02700	47-00-02	61	2	32B61-02100	61-00-01	69	15
32A30-16012	30	35	1	32A47-02800	47-00-01	59	3	32B61-02200	61-00-01	69	16
32A32-00200	32	39	2	32A47-02800	47-00-02	61	3	32B61-02300	61-00-01	69	17
32A32-00200	94	109	1 22	32A47-05010	47-00-01	59	1	32B61-02400	61-00-01	69	18
32A32-01400	92	107	1	32A47-05011	47-00-02	61	1	32C04-04501	04	7	8 05
32A32-01400	94	109	1 23	32A47-05600	47-00-01	59	1 06	32C48-01105	48-02	65	1
32A32-03300	94	109	1 43	32A47-05600	47-00-02	61	1 06	32C61-06000	61-00-01	69	1
32A32-21100	32	39	1	32A47-05700	47-00-01	59	1 07	32C61-06000	61-00-02	71	1
32A35-00600	35	41	2	32A47-05700	47-00-02	61	1 07	32C61-06010	61-00-02	71	1 01
32A35-00600	94	109	1 09	32A47-05800	47-00-01	59	1 01	34232-00300	94	109	1 29
32A35-10012	35	41	1	32A47-05801	47-00-02	61	1 01	34232-08200	32	39	4
32A35-12101	23	33	6	32A47-05900	47-00-01	59	1 08	34287-02602	87-05	105	1
32A35-16101	35-02	43	1	32A47-06100	47-00-01	59	1 03	34287-02603	87-05	105	1
32A36-05012	36	45	1	32A47-06100	47-00-02	61	1 03	34307-02100	07	13	5
32A36-30100	65-01-01	77	7	32A48-00400	48	63	2	34323-00801	23	33	4
32A39-01100	39	47	1	32A61-00900	65-01-01	77	8	34330-04300	30-02	37	2

NUMERICAL PARTS INDEX

PART NO.	GRP NO.	PAGE-NO.	REF.	PART NO.	GRP NO.	PAGE-NO.	REF.	PART NO.	GRP NO.	PAGE-NO.	REF.
34330-04300	94	109	1 30	94901-34090	65-01-06	91	1 26	94918-00310	65-01-04	85	1 44
34336-04100	94	111	1 46	94901-34100	65-01-05	87	1 24	94918-00310	65-01-07	95	1 20
34340-00700	36	45	2	94901-34100	65-01-06	91	1 26				
34340-00700	94	109	1 03	94901-50500	65-01-02	79	1 06				
34404-02901	04	7	5	94901-50500	65-01-03	81	1 06				
34407-11090	12	19	5	94901-50500	65-01-05	87	1 21				
34446-05300	94	109	1 31	94901-50500	65-01-06	91	1 23				
34461-09050	65-01-02	79	1 07	94901-81020	65-01-05	89	1 60				
34461-09050	65-01-03	81	1 07	94901-81020	65-01-06	93	1 70				
34461-09050	65-01-07	95	1	94901-81240	65-01-07	95	1 16				
34462-00011	62	75	1	94901-81550	65-01-05	87	1 44				
34462-00201	62	75	1 01	94901-81550	65-01-06	93	1 54				
34462-00300	62	75	1 02	94904-30010	65-01-04	83	1 02				
34661-02000	61-00-02	73	1 08	94904-32250	65-01-05	87	1 39				
36730-01101	30-02	37	1	94904-32250	65-01-06	93	1 47				
42713-30600	47-00-01	59	1 05	94904-71190	65-01-05	87	1 35				
42713-30600	47-00-02	61	1 05	94904-71190	65-01-06	93	1 44				
42786-03300	47-00-01	59	1 02	94904-71360	65-01-04	85	1 35				
42786-03300	47-00-01	59	7	94904-71750	65-01-05	87	1 32				
42786-03300	47-00-02	61	1 02	94904-71750	65-01-06	91	1 41				
42786-03300	47-00-02	61	7	94904-71760	65-01-05	87	1 31				
90160-06051	65-01-04	85	1 33	94904-71760	65-01-06	91	1 40				
90190-08051	65-01-05	89	1 64	94904-72701	65-01-05	89	1 62				
90190-08051	65-01-06	91	1 15	94904-72701	65-01-06	93	1 49				
90258-06001	65-01-04	85	1 34	94905-02450	65-01-02	79	1 04				
90400-02101	65-01-05	87	1 13	94905-02450	65-01-03	81	1 04				
90400-02101	65-01-06	91	1 14	94905-03390	65-01-05	89	1 59				
90801-10120	65-01-05	89	1 61	94905-03390	65-01-06	93	1 69				
90801-10120	65-01-06	93	1 71	94906-21270	65-01-05	87	1 45				
90801-20160	65-01-05	87	1 27	94906-21270	65-01-06	93	1 55				
90801-20160	65-01-06	91	1 29	94907-10090	65-01-05	87	1 28				
91418-06161	65-01-02	79	1 09	94907-10090	65-01-06	91	1 30				
91418-06161	65-01-03	81	1 09	94907-20940	65-01-07	95	1 14				
91418-06161	65-01-05	87	1 40	94910-00010	65-01-05	87	1 18				
91418-06161	65-01-06	93	1 50	94910-00010	65-01-06	91	1 20				
91518-08221	65-01-02	79	1 08	94910-10120	65-01-04	85	1 36				
91518-08221	65-01-03	81	1 08	94913-00030	65-01-05	89	1 56				
94805-30051	65-01-05	87	1 14	94913-00030	65-01-06	93	1 66				
94805-30051	65-01-06	91	1 16	94913-00050	65-01-05	87	1 19				
94901-33880	65-01-06	91	1 38	94913-00050	65-01-06	91	1 21				
94901-34020	65-01-06	91	1 38	94913-00190	65-01-02	79	1 05				
94901-34030	65-01-06	91	1 38	94913-00190	65-01-03	81	1 05				
94901-34040	65-01-06	91	1 38	94914-00130	65-01-05	89	1 47				
94901-34060	65-01-05	87	1 24	94914-00130	65-01-06	93	1 57				
94901-34060	65-01-06	91	1 26	94914-00380	65-01-04	85	1 42				
94901-34070	65-01-05	87	1 24	94914-02570	65-01-04	83	1 25				
94901-34070	65-01-06	91	1 26	94915-00210	65-01-05	87	1 33				
94901-34080	65-01-05	87	1 24	94915-00210	65-01-06	91	1 42				
94901-34080	65-01-06	91	1 26	94915-02700	65-01-07	95	1 21				
94901-34090	65-01-05	87	1 24	94918-00060	65-01-04	85	1 43				

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1805-06010	F1035-06010 F2515-06000	F1805-06035	F1035-06035 F2515-06000	F1805-08018	F1035-08018 F2515-08000
F1805-06012	F1035-06012 F2515-06000	F1805-06040	F1035-06040 F2515-06000	F1805-08020	F1035-08020 F2515-08000
F1805-06014	F1035-06014 F2515-06000	F1805-06045	F1035-06045 F2515-06000	F1805-08022	F1035-08022 F2515-08000
F1805-06016	F1035-06016 F2515-06000	F1805-06055	F1035-06055 F2515-06000	F1805-08025	F1035-08025 F2515-08000
F1805-06018	F1035-06018 F2515-06000	F1805-06060	F1035-06060 F2515-06000	F1805-08030	F1035-08030 F2515-08000
F1805-06020	F1035-06020 F2515-06000	F1805-08012	F1035-08012 F2515-08000	F1805-08035	F1035-08035 F2515-08000
F1805-06025	F1035-06025 F2515-06000	F1805-08014	F1035-08014 F2515-08000	F1805-08040	F1035-08040 F2515-08000
F1805-06030	F1035-06030 F2515-06000	F1805-08016	F1035-08016 F2515-08000	F1805-08045	F1035-08045 F2515-08000

TABLE OF BOLT, W/WASHER

BOLT, W/WASHER	BOLT/WASHER	BOLT, W/WASHER	BOLT/WASHER	BOLT, W/WASHER	BOLT/WASHER
F1805-08050	F1035-08050 F2515-08000	F1805-10018	F1035-10018 F2515-10000	F1805-10050	F1035-10050 F2515-10000
F1805-08055	F1035-08055 F2515-08000	F1805-10020	F1035-10020 F2515-10000	F1805-10055	F1035-10055 F2515-10000
F1805-08060	F1035-08060 F2515-08000	F1805-10022	F1035-10022 F2515-10000	F1805-10060	F1035-10060 F2515-10000
F1805-08065	F1035-08065 F2515-08000	F1805-10025	F1035-10025 F2515-10000	F1805-10065	F1035-10065 F2515-10000
F1805-08070	F1035-08070 F2515-08000	F1805-10030	F1035-10030 F2515-10000	F1805-10070	F1035-10070 F2515-10000
F1805-08075	F1035-08075 F2515-08000	F1805-10035	F1035-10035 F2515-10000	F1805-10085	F1035-10085 F2515-10000
F1805-10014	F1035-10014 F2515-10000	F1805-10040	F1035-10040 F2515-10000	F1805-12016	F1035-12016 F2515-12000
F1805-10016	F1035-10016 F2515-10000	F1805-10045	F1035-10045 F2515-10000	F1805-12020	F1035-12020 F2515-12000

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1805-12025	F1035-12025 F2515-12000	F1805-12065	F1035-12065 F2515-12000	F1825-06010	F1035-06010 F2515-06000 F2500-06000
F1805-12030	F1035-12030 F2515-12000	F1805-12085	F1035-12085 F2515-12000	F1825-06012	F1035-06012 F2515-06000 F2500-06000
F1805-12035	F1035-12035 F2515-12000	F1805-14035	F1035-14035 F2515-14000	F1825-06014	F1035-06014 F2515-06000 F2500-06000
F1805-12040	F1035-12040 F2515-12000	F1805-14045	F1035-14045 F2515-14000		
F1805-12045	F1035-12045 F2515-12000			F1825-06016	F1035-06016 F2515-06000 F2500-06000
F1805-12050	F1035-12050 F2515-12000			F1825-06020	F1035-06020 F2515-06000 F2500-06000
F1805-12055	F1035-12055 F2515-12000			F1825-06025	F1035-06025 F2515-06000 F2500-06000
F1805-12060	F1035-12060 F2515-12000				

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1825-06030	F1035-06030	F1825-08025	F1035-08025	F1825-08050	F1035-08050
	F2515-06000		F2515-08000		F2515-08000
	F2500-06000		F2500-08000		F2500-08000
F1825-06035	F1035-06035	F1825-08030	F1035-08030	F1825-08055	F1035-08055
	F2515-06000		F2515-08000		F2515-08000
	F2500-06000		F2500-08000		F2500-08000
F1825-06055	F1035-06055	F1825-08035	F1035-08035	F1825-08085	F1035-08085
	F2515-06000		F2515-08000		F2515-08000
	F2500-06000		F2500-08000		F2500-08000
F1825-08012	F1035-08012	F1825-08038	F1035-08038	F1825-10014	F1035-10014
	F2515-08000		F2515-08000		F2515-10000
	F2500-08000		F2500-08000		F2500-10000
F1825-08016	F1035-08016	F1825-08040	F1035-08040	F1825-10016	F1035-10016
	F2515-08000		F2515-08000		F2515-10000
	F2500-08000		F2500-08000		F2500-10000
F1825-08020	F1035-08020	F1825-08045	F1035-08045	F1825-10020	F1035-10020
	F2515-08000		F2515-08000		F2515-10000
	F2500-08000		F2500-08000		F2500-10000

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1825-10025	F1035-10025	F1825-12025	F1035-12025	F2005-10016	F1155-10016
	F2515-10000		F2515-12000		F2515-10000
	F2500-10000		F2500-12000		
F1825-10030	F1035-10030	F1825-12030	F1035-12030	F2005-10020	F1155-10020
	F2515-10000		F2515-12000		F2515-10000
	F2500-10000		F2500-12000		
F1825-10035	F1035-10035	F1825-12040	F1035-12040	F2005-10025	F1155-10025
	F2515-10000		F2515-12000		F2515-10000
	F2500-10000		F2500-12000		
F1825-10040	F1035-10040			F2005-10030	F1155-10030
	F2515-10000				F2515-10000
	F2500-10000				
F1825-10080	F1035-10040			F2005-10035	F1155-10035
	F2515-10000				F2515-10000
	F2500-10000				
F1825-10080	F1035-10080			F2005-10040	F1155-10040
	F2515-10000				F2515-10000
	F2500-10000				
F1825-12020	F1035-10080			F2005-10045	F1155-10045
	F2515-10000				F2515-10000
	F2500-10000				
F1825-12020	F1035-12020			F2005-10050	F1155-10050
	F2515-12000				F2515-10000
	F2500-12000				

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F2005-10055	F1155-10055 F2515-10000	F2005-12040	F1155-12040 F2515-12000	F2015-10020	F1155-10020 F2515-10000 F2500-10000
F2005-10060	F1155-10060 F2515-10000	F2005-12045	F1155-12045 F2515-12000	F2015-10025	F1155-10025 F2515-10000 F2500-10000
F2005-10065	F1155-10065 F2515-10000	F2005-12050	F1155-12050 F2515-12000	F2015-10030	F1155-10030 F2515-10000 F2500-10000
F2005-10070	F1155-10070 F2515-10000	F2005-12055	F1155-12055 F2515-12000	F2015-10035	F1155-10035 F2515-10000 F2500-10000
F2005-12020	F1155-12020 F2515-12000	F2005-12065	F1155-12065 F2515-12000	F2015-10040	F1155-10040 F2515-10000 F2500-10000
F2005-12025	F1155-12025 F2515-12000			F2015-10050	F1155-10050 F2515-10000 F2500-10000
F2005-12030	F1155-12030 F2515-12000				
F2005-12035	F1155-12035 F2515-12000				

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F2015-10055	F1155-10055 F2515-10000 F2500-10000				
F2015-10060	F1155-10060 F2515-10000 F2500-10000				
F2015-12025	F1155-12025 F2515-12000 F2500-12000				
F2015-12030	F1155-12030 F2515-12000 F2500-12000				