

MITSUBISHI GENUINE PARTS

“MITSUBISHI GENUINE PARTS” should be used exclusively for servicing your Mitsubishi engine.

“MITSUBISHI GENUINE PARTS” are superior and reliable because they have been produced under the excellent quality-control system, and have passed the strict inspections.

Imitation parts are not reliable from the viewpoints of their material and manufacturing method which are entirely incomparable with those of genuine parts.

A large assortment of “MITSUBISHI GENUINE PARTS” is always available at any of our authorized dealers, so do your ordering at your nearest dealer by specifying “MITSUBISHI GENUINE PARTS”.

GUIDE FOR USE OF PARTS CATALOGUE

1. This Parts Catalogue contains service parts for the following Mitsubishi S4S diesel engine.
Then applicable engine type and serial number are as follows:

ENGINE NAME	MODEL	USE-SPECIFICATION	APPLICABLE SERIAL NO.
S4S	Y365DP	For POWER UNIT	XXXXXX-UP
	Y367DP		XXXXXX-UP
	Y368DP		194905-UP

2. When ordering parts, give the Mitsubishi dealer or distributor the following information:
 - (1) Part number (or assembly number) and part name.
 - (2) Quantity required
 - (3) Model and serial number

NOTE: In some cases, a substitute part is furnished instead of the part ordered.
3. Indication of assembled bolts with washer
Of the standard bolts, those with washers are identified by the symbol "B/W" in the Description column of each list. (Part Name: BOLT, W/WASHER)
For the part numbers of the bolts, washers and those of bolts with washers, refer to the listing (beginning with the page D1) at the end of this parts catalogue. These bolts and washers should be ordered individually.
4. For the numerical index, refer to the page beginning with C1 at the end of this parts catalogue.
5. Some illustration may have some difference from the shape of real part when the illustration Shows a representation of various parts.
6. The parts and part numbers are subject to change without prior notice.

SAMPLE OF PARTS CATALOGUE

Group number

Group name

07-01 CRNAKCASE ASSY

Model type

When these column is blank, it is applicable from serial No. shown on cover and up.

REF. -NO.	PART NO.	R / P	S E N G Q	PART NAME & DESCRIPTION	MODEL&QTY			APPLICABLE SERIAL NO.		M / V / R / D
					Y365DP	Y367DP	Y368DP	FROM@	-@UPTO	
1	31B07-52010			CRANKCASE ASSY	1	1	1			
2	*			CRANKCASE SUB ASSY	1	1	1			A
2 01	04826-22000			CAP,SEALING	2	2	2			A
2 02	04826-23500			CAP,SEALING	2	2	2			
2 03	31A07-00801			CAP,MAIN BEARING	8	8	8			
2 04	*			CRANKCASE	1	1	1			
2 05	32507-02500		C	HANGER	1	1	1		-011285	V
2 06	32507-02700	N	1	HANGER	1	1	1	011286-		
2 07	32507-04100		Q	SHIM	1	1	.		@011294	
2 08	32507-04100		1	SHIM	1	1	1	011295@		
2 09	F1805-10025			BOLT,W/WASHER	1	1	1			A
				See(8)-(a)Description Codes.	Quantity per unit.			High-demand part. See(11).		
				See(8)-(c)Specification codes.	Applicable from serial No. indicated.			Part newly changed or added. See(12).		
				See(8)-(b)Description.	Applicable from 011295 (Scheduled)if suffixed with @ and sometimes differs from real serial No.			Applicable up to 011294 (Scheduled)if prefixed with @ and sometimes differs from real serial No.		
				See(6)Change codes.	Applicable up to serial No. indicated.					
				See(5)Sequence-of-change numbers.						
				See(2)Reference number.						
				See(4)Interchangeability codes.						
				Part not to be Supplied. See(3).						

NOTE :Some of model designations, number of variations and serial numbers, indicated above, are quoted from other parts catalogues.
Read these items of information as those for this parts catalogue.

NOTE: For the description of each item, refer to the pages which follow.

HOW TO USE THIS PARTS CATALOGUE

(to be referred to together with the former SAMPLE OF PARTS CATALOGUE)

(1) 01 CYLINDER HEAD

- 3 -

REF. -NO.	PART NO.	R / P	S C E N Q G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
					Y365DP	Y367DP	Y368DP	FROM	TO		
1	32A01-21020			HEAD ASSY, CYLINDER	1	1	1				
2	*			HEAD SUB ASSY, CYL	1	1	1				
2 01	04826-22000			CAP, SEALING	8	8	8				
2 02	04826-22500			CAP, SEALING	7	7	7				
2 03	32A01-01600			GUIDE, VALVE	8	8	8				

(2) (3) (4)(5)(6) (7) (8) (9) (10) (11)(12)

The items (1) thru (12) are as described below:

(1) Compiling system

The systems of a unit are grouped according to their location in the unit. The groups, each identified by group number, are listed in the order by CONTENTS. Each group is preceded by an "exploded view" which clearly illustrates each part in its correct relation to the other parts in the illustration.

(2) Reference number

Abbreviated to "REF. No.," this number is used to locate a part in the illustration. In cases that the reference number is of three to four digits, the first and second digits show the reference number of an assembly, and the last two digits show the numbers of its component parts.

(3) Part numbers

The part numbers shown in this parts catalogue are those assigned to genuine Mitsubishi parts.

NOTE: Parts with asterisk (*) are not supplied individually.

(4) Interchangeability codes

The interchangeability codes used in this parts catalogue are as follows:

PART NO.	Code (R/P)	DESCRIPTION
A(Old) B(New)	R	B(new part) and A(old part) are mutually interchangeable
A(Old) B(New)	1	A(Old part) is not supplied. B(new part) can be substituted for A(Old part).
A(Old) B(New)	3	B(new part) can be substituted for A(old part). [A(old part) cannot be substituted for B(new part).]
A(Old) B(New)	N	B(new part) and A(old part) are not interchangeable.
A(Old) B(New)	G	B(new part) can be substituted for A(old part) in combination with other part(s). (For the parts to be combined, refer to the listing beginning with the page E1 at the end of this parts catalogue.)

(5) Sequence-of-change numbers

The parts are changed for improved quality or performance. Their changes are indicated in sequence by numerals (1.2.3...).

Blank : Original

1 : 1st change

2 : 2nd change

3 : 3rd change

(6) Change codes

These codes indicate the reason or purpose of changes of the parts.

A : Added part (a part entered into service)

C : Change of part number

D : Deleted part (a part applicable up to the serial no. expressed in Serial No. column)

E : Added part except above reasons

Q : Change of quantity

(7) Part name

Abbreviations are sometimes used. For the abbreviations, refer to TABLE OF SYMBOLS & ABBREVIATIONS appeared in hind pages of this general information chapter.

NOTE: The location terms L.H (left hand) and R.H(right hand) are as these directions viewed from the flywheel side of an engine.

(8) Description & Abbreviation codes

(a) Description codes (expressed in the first part of Description column).

B/W: Assembled bolt (with washer)

KIT: Part supplied as a kit

STD: Standard part

OPT: Optional part

AR : Part used, as required or by selection or in adjust quantity for necessity

SFN: Semi-finished part

(b) The Description codes in above paragraph (a) are followed by supplementary explanation such as dimensions (thickness, length, etc.) ,manufacturer part number, manufacturer name, etc. as occasion demands.

NOTE: Unless otherwise indicated, the dimensions are shown in millimeter and the name of unit is abbreviated.

(Examples) Thickness: T=1.00 Length: L=1000

Width: W=1500 Height: H=500

(c) Specification codes

Each specification or type of model, and selective specifications of a unit are indicated by codes of three digits. For these codes, refer to LIST OF SPECIFICATION CODES appeared in hind pages of this general information chapter.

NOTE: Unless indicated by the specification codes, the parts may be used for the products of all specifications.

(Examples) A10:For diesel fuel
B10:With industrial electric starter

(d) The parts indicated as "NOT SHOWN", such as component parts of overhaul gasket kit, are not shown in the illustration.

(9) Model & quantity

- (a) Model : Model, type, specification, destination, etc. of product to which a parts catalogue applies are indicated in the title column of each variation.
- (b) Quantity :Quantity of part or assembly, and its component parts required for one unit of product is indicated.

NOTE: In case "AR" appears in QTY column, it is required to adjust quantity for use.

(10) Applicable serial numbers

Applicable serial numbers of engine are indicated in the "UPTO" or "FROM" column. Serial numbers with "@" are scheduled ones and sometimes differ from the real serial numbers. If the "FROM " column is blank, the part is applicable to serial number shown on this cover and up.

(11) Management rank

The parts ranked as "A" are high-demand parts. This ranking is to be referred to by dealers, and is devised to facilitate and rationalize their distribution, stocking and inventory of the parts.

(12) The parts changed or added after the last parts list that has been published are identified by "V."

TABLE OF SYMBOLS & ABBREVIATIONS

SYMBOL	DESCRIPTION		SYMBOL	DESCRIPTION	
ACCEL	ACCELERATOR		ELEC	ELECTRIC	
ADJ	ADJUSTING (ADJUSTABLE)		ENG	ENGINE	
AIR-CON	AIR-CONDITIONER		EQUIP	EQUIPMENT	
ASSY	ASSEMBLY		EXH	EXHAUST	
ATT	ATTACHMENT		E/TNK	EXPANSION TANK	
AUTO	AUTOMATIC		FITT	FITTING	
AUX	AUXILIARY		FLEX	FLEXIBLE	
AR	AS REQUIRED		FR	FRONT	
B/H	BACKHOE		GSKT	GASKET	
BATT	BATTERY		GEN	GENERATOR	
BRG	BEARING		GOV	GOVERNOR	
B/PMP	BILGE PUMP		G/N	GROUP NUMBER	
BRKT	BRACKET		H/EXCH	HEAT EXCHANGER	
BUSH	BUSHING		HEX	HEXAGON	
CARB	CARBURETOR		HYD	HYDRAULIC	
C/L	CENTERLINE		H=	HEIGHT	
COMPR	COMPRESSOR		IND	INDUSTRIAL	
CON-ROD	CONNECTING-ROD		INJ	INJECTION	
C/MBR	CROSS-MEMBER		INSTAL	INSTALLATION	
CYL	CYLINDER		INST	INSTRUMENT	
DIA	DIAMETER		INTLK	INTERLOCK	
DIFF	DIFFERENTIAL		JUNC	JUNCTION	
DISTR	DISTRIBUTOR		KD	KNOCKDOWN	
DR	DRIVE		L.H	LEFT HAND	
D=	OUT DIAMETER		LUB	LUBRICATION	
			L=	LENGTH	

TABLE OF SYMBOLS & ABBREVIATIONS

SYMBOL	DESCRIPTION		SYMBOL	DESCRIPTION	
MANF	MANIFOLD		STD	STANDARD	
MAX	MAXIMUM		SUPT	SUPPORT	
M.L.H	MAXIMUM LIFTING HEIGHT		SYM	SYMBOL	
MIN	MINIMUM		SYNCH	SYNCHRONIZER	
MTR	MOTOR		SYS	SYSTEM	
MTG	MOUNTING		TEMP	TEMPERATURE	
NO.	NUMBER		TERM	TERMINAL	
OPT	OPTION		T/CONV	TORQUE-CONVERTER	
O/D	OVER DRIVE		T/F	TRANSFER	
O.S	OVERSIZE		T/M	TRANSMISSION	
PTO	POWER TAKE-OFF		T/HSG	TURBINE-HOUSING	
P/S	POWER STEERING		T/C	TURBOCHARGER	
PRESS	PRESSURE		T=	THICKNESS	
P/N	PART NUMBER		U/BODY	UNDERBODY	
QTY	QUANTITY		U.S	UNDERSIZE	
			UNIV	UNIVERSAL	
RAD	RADIATOR		VAC	VACUUM	
RE	REAR		VENT	VENTILATOR	
REG	REGULATOR		W/STRIP	WEATHERSTRIP	
REV	REVERSE		W/	WITH	
R.H	RIGHT HAND		W/O	WITHOUT	
REF.NO.	REFERENCE		W/W	WOODWARD	
R/N	REFERENCE		W/PMP	WATER PUMP	
S/PMP	SEA WATER PUMP		W=	WIDTH	
SECT	SECTION		Z=	NUMBER OF GEAR TEETH	
S/MBR	SIDEMEMBER				

TABLE OF SYMBOLS & ABBREVIATIONS

SYMBOL	DESCRIPTION		SYMBOL	DESCRIPTION	
1ST	FIRST				
2ND	SECOND				
3RD	THIRD				
4TH	FOURTH				
5TH	FIFTH				
&	AND				
@	UNCONFIRMED				
*	PART NOT TO BE SUPPLIED				

CONTENTS


GROUP NO.	GROUP NAME	PAGE
ENGINE BODY		
01	CYLINDER HEAD	2
01-02	LIFTING EYE	4
04	VALVE MECHANISM	6
04-02	ROCKER COVER	8
05	CAMSHAFT & TAPPET	10
07	CRANKCASE	12
09	MAIN BEARING	14
11-00-01	TIMING GEAR CASE (FOR Y365DP,Y367DP)	16
11-00-02	TIMINNG GEAR CASE(FOR Y368DP)	18
12	FLYWHEEL HOUSING	20
13	OIL PAN & OIL LEVEL GAGE	22
17	PISTON	24
19	CONNECTING-ROD	26
20	CRANKSHAFT	28
20-02	CRANK PULLEY	30
21	FLYWHEEL	32
23-00-01	TIMING GEAR(FOR Y365DP,Y367DP)	34
23-00-02	TIMING GEAR(FOR Y368DP)	36
25	SIDE PTO(FOR Y368DP)	38
INLET & EXHAUST SYSTEM		
30	INLET SYSTEM	40
30-02	INLET PIPE	42
32	EXHAUST SYSTEM	44
OIL SYSTEM		
35	OIL PUMP	46
35-02	OIL STRAINER	48
36	OIL SYSTEM	50

GROUP NO.	GROUP NAME	PAGE
39	OIL COOLER	52
40	OIL FILTER	54
43	BREATHER	56
COOLING SYSTEM		
45	WATER PUMP	58
45-02	WATER PUMP & PULLEY	60
46	COOLING SYSTEM	62
48	FAN	64
48-02	FAN SPACER	66
49	V-BELT	68
FUEL SYSTEM		
61-00-01	FUEL SYSTEM	70
61-00-02	NOZZLE	72
62	FUEL FILTER	76
65-03-01	INJECTION PUMP	78
65-03-02	INJECTION PUMP GENERAL	80
65-03-03	INJECTION PUMP ASSY	90
ELECTRIC PARTS		
66	STARTER(12V-2.2KW)	92
66-02	GLOW PLUG & WIRE	94
68-00-01	ALTERNATOR(FOR Y365DP,Y367DP)	96
68-00-02	ALTERNATOR(FOR Y368DP)	98
68-00-03	ALTERNATOR(12V-50A)	100
INSTRUMENT		
90	INSTRUMENT	102
REPAIR PARTS		
94-00-01	OVERHAUL GASKET KIT (FOR Y365DP,Y367DP)	104
94-00-02	OVERHAUL GASKET KIT (FOR Y368DP)	108
NUMERICAL PARTS INDEX		C1


GROUP NO.	GROUP NAME	PAGE
TABLE OF BOLT,W/WASHER.....		D1

01


CYLINDER HEAD



REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A01-21020				HEAD ASSY,CYLINDER	1	1	1				
2	*				HEAD SUB ASSY,CYL	1	1	1				
2 01	04826-22000				CAP,SEALING	8	8	8				
2 02	04826-22500				CAP,SEALING	7	7	7				
2 03	32A01-01600				GUIDE,VALVE	8	8	8				
2 04	32A01-03100				SEAT,VALVE, IN	4	4	4				
2 05	32A01-03200				SEAT,VALVE,EX	4	4	4				
2 06	*				HEAD,CYLINDER	1	1	1				
2 07	32A03-01100				JET,COMBUSTION	4	4	4				
3	*				PLUG	1	1	1				
4	32A01-01400				BOLT,CYLINDER HEAD	17	17	17				
5	32A01-02204				GASKET,CYL.HEAD	1	1	1			A	
6	MM316248				PLUG,DRAIN	1	1	1			A	
7	30636-25901				GASKET	1	1	1			A	




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A01-02700				EYE,LIFTING FRONT	1	1	1				
2	32A01-02800				EYE,LIFTING REAR	1	1	1				
3	32A01-02501				GASKET,HEAD REAR	1	1	1			A	
4	MF240051				BOLT,W/WASHER	2	2	2			A	
5	MF240053				BOLT,W/WASHER	4	4	4			A	




REF. NO. 5 COMES IN PAIRS.

REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A04-20100				VALVE, INLET	4	4	4				
2	32A04-21100				VALVE, EXHAUST	4	4	4				
3	30604-21402				SPRING, VALVE	8	8	8			A	
4	30604-31601				RETAINER, UPPER	8	8	8				
5	34404-02901				COTTER, VALVE	16	16	16			A	
6	31304-11700				CAP	8	8	8				
7	32A04-02801				SEAL, VALVE STEM	8	8	8			A	
8	*				ROCKER & SHAFT ASSY	1	1	1				
8 01	32A04-04011				SHAFT ASSY, ROCKER	1	1	1				
8 02	04826-21200				CAP, CEALING	2	2	2				
8 03	*				SHAFT, ROCKER	1	1	1				
8 04	32A04-04701				BRACKET, ROCKER SHAFT	4	4	4				
8 05	32A04-04801				BOLT, ROCKER BRACKET	4	4	4				
8 06	32A04-22010				ROCKER	8	8	8				
8 07	F2325-08000				NUT, JAM	8	8	8			A	
8 08	32A04-02401				SCREW, ROCKER	8	8	8				
8 09	*				ROCKER & BUSHING	8	8	8				
8 10	32C04-04501				SPRING, ROCKER	3	3	3				
8 11	MF241255				BOLT, W/WASHER	4	4	4			A	
8 12	MF522010				RING, SNAP	2	2	2			A	


04-02 ROCKER COVER






REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A05-00101				CAMSHAFT	1	1	1				
2	F2870-07022				KEY, WOODRUFF	1	1	1				
3	30405-31403				PLATE, THRUST	1	1	1				
4	MF241251				BOLT, W/WASHER	2	2	2			A	
5	32A05-02101				TAPPET	8	8	8				
6	32A05-13100				ROD, PUSH	8	8	8				

07 CRANKCASE




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A07-41010				CRANKCASE ASSY	1	1	1				
2	*				CRANKCASE SUB ASSY	1	1	1				
2 01	04826-23500				CAP, SEALING	10	10	10				
2 02	*				CAP, BEARING	4	4	4				
2 03	*				CAP, BEARING REAR	1	1	1				
2 04	32A07-02600				BOLT, BEARING CAP	10	10	10			A	
2 05	*				CRANKCASE	1	1	1				
3	04826-21800				CAP, SEALING	4	4	4			A	
4	04827-90170				PLUG, TAPERED	1	1	1				
5	*				PLUG	3	3	3				
6	34307-02100				PLUG, CAM	1	1	1			A	
7	32A07-01501				PIN, DOWEL	2	2	2			A	
8	F2846-12000				PIN, DOWEL	2	2	2			A	
9	F2846-05000				PIN, DOWEL	2	2	2			A	
10	F2850-04008				PIN, SPRING	6	6	6			A	
11	05605-01410				BUSHING	1	1	1				
12	32A23-03500				SHAFT, IDLER	1	1	1				
13	MD000269				PLUG, TAPERED	1	1	1			A	
14	MS661140				PLUG, TAPERED	7	7	7			A	
15	MS661142				PLUG, TAPERED	1	1	1			A	
16	32A07-11700				SEAL, SIDE	2	2	2			A	




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A09-00010				BEARING SET,MAIN	1	1	1			A	
1 01	*				MAIN BEARING,LOWER	5	5	5				
1 02	*				MAIN BEARING,UPPER	5	5	5				
2	32A09-00020				BEARING SET,MAIN	1	1	1			A	
3	32A09-00030				BEARING SET,MAIN	1	1	1			A	
4	32A09-00040				BEARING SET,MAIN	1	1	1			A	
5	32B09-08101				PLATE,THRUST	3	3	3				
6	32B09-08201				PLATE,THRUST	3	3	3				
7	32B09-08301				PLATE,THRUST	3	3	3				

**11-00-01 TIMING GEAR CASE
(FOR Y365DP,Y367DP)**




2009-05-26 615A30-00

11-00-02 TIMING GEAR CASE(FOR Y368DP)




2009-05-26 615A30-00




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32B12-00301				HOUSING, FLYWHEEL	1	•	•				
2	32B12-00700				HOUSING, FLYWHEEL	•	1	1				
3	32A07-14201				GASKET, REAR	1	1	1			A	
4	MF241282				BOLT, W/WASHER	10	10	10			A	
5	MF241284				BOLT, W/WASHER	2	2	2			A	
6	34407-11090				SEAL ASSY, OIL	1	1	1			A	
7	MF407726				STUD	2	2	2				
8	F2300-10000				NUT	2	2	2			A	
9	F2515-10000				WASHER, SPRING	2	2	2			A	
10	MM316248				PLUG, DRAIN	1	2	2			A	
11	30636-25901				GASKET	1	2	2			A	
12	MD001404				PLUG, DRAIN	1	•	•			A	
13	MD000312				GASKET, OIL DRAIN	1	•	•			A	


13 OIL PAN & OIL LEVEL GAGE




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A13-00011				PAN ASSY,OIL	1	1	1				
1 01	*				PAN,OIL	1	1	1				
1 02	MD050316				PLUG,OIL DRAIN	1	1	1			A	
1 03	MD050317				GASKET,OIL DRAIN	1	1	1			A	
2	MF240051				BOLT,W/WASHER	24	24	24			A	
3	32A42-05100				GAGE,OIL LEVEL	1	1	1				




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A17-10100				PISTON	4	4	4			A	
2	32A17-10200				PISTON	4	4	4			A	
3	32A17-10300				PISTON	4	4	4			A	
4	32A17-02010				RING SET,PISTON	4	4	4			A	
4 01	*				RING,NO.1	4	4	4				
4 02	*				RING,NO.2	4	4	4				
4 03	*				RING,OIL	4	4	4				
5	32A17-02020				RING SET,PISTON	4	4	4			A	
6	32A17-02030				RING SET,PISTON	4	4	4			A	
7	32A17-08300				PIN,PISTON	4	4	4			A	
8	F3202-03000				RING,SNAP	8	8	8			A	







REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A20-00052				CRANKSHAFT ASSY	1	1	•				
1 01	*				CRANKSHAFT	1	1	•				
1 02	F2846-10000				PIN,DOWEL	2	2	•			A	
1 03	F2870-07022				KEY,WOODRUFF	2	2	•				
1 04	32A20-02902				NUT,CRANKSHAFT	1	1	•				
1 05	32A23-00301				GEAR,CRANKSHAFT	1	1	•				
2	32A20-00044				CRANKSHAFT ASSY	•	•	1				
2 01	*				CRANKSHAFT	•	•	1			A	
2 02	F2846-10000				PIN,DOWEL	•	•	2				
2 03	F2870-07022				KEY,WOODRUFF	•	•	2				
2 04	32A20-02902				NUT,CRANKSHAFT	•	•	1				
2 05	32A23-00200				GEAR,CRANKSHAFT	•	•	1				




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A20-02203				PULLEY, CRANKSHAFT	1	1	1				

21 FLYWHEEL




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A21-00051				FLYWHEEL ASSY	1	•	•				
1 01	32A21-00900				GEAR,RING	1	•	•				
1 02	*				FLYWHEEL	1	•	•				
2	F1035-12035				BOLT	4	•	•			A	
3	F2515-12000				WASHER, SPRING	4	•	•			A	
4	32B21-05010				FLYWHEEL ASSY	•	1	1				
4 01	32A21-00900				GEAR,RING	•	1	1				
4 02	*				FLYWHEEL	•	1	1				
5	92233-31600				BOLT	•	4	4			A	
6	32B21-05200				ADAPTER, BEARING	•	1	1				
7	F2005-10025				BOLT, W/WASHER	•	4	4			A	

23-00-01 TIMING GEAR(FOR Y365DP,Y367DP)




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A23-01101				GEAR,CAMSHAFT	1	1	•				
2	32A23-05101				GEAR, INJECTION PUMP	1	1	•				
3	32A23-03040				IDLER ASSY,GEAR	1	1	•				
3 01	*				GEAR, IDLER	1	1	•				
3 02	32A23-03200				BUSHING, IDLER	1	1	•				
4	34323-00801				PLATE, THRUST	1	1	•				
5	MF241280				BOLT,W/WASHER	1	1	•			A	
6	32A35-12101				GEAR,OIL PUMP	1	1	•				


23-00-02 TIMING GEAR(FOR Y368DP)



REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A23-01200				GEAR,CAMSHAFT	•	•	1				
2	32A23-02900				GEAR, INJECTION PUMP	•	•	1				
3	32A23-03030				IDLER ASSY,GEAR	•	•	1				
3 01	*				GEAR, IDLER	•	•	1				
3 02	32A23-03200				BUSHING, IDLER	•	•	1				
4	34323-00801				PLATE, THRUST	•	•	1				
5	MF241280				BOLT,W/WASHER	•	•	1			A	
6	32A35-22202				GEAR,OIL PUMP	•	•	1				





2009-05-26 615A30-00




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A30-16012				MANIFOLD ASSY, INLET	1	1	1				
1 01	32A04-09100				PIPE, BREATHER	1	1	1				
1 02	*				MANIFOLD, INLET	1	1	1				
2	32A30-00201				GASKET, INLET MANF	1	1	1			A	
3	MF241261				BOLT, W/WASHER	14	14	14			A	
4	F1035-08090				BOLT	2	2	2			A	
5	F2515-08000				WASHER, SPRING	2	2	2			A	


30-02 INLET PIPE









[illegible]







[illegible]




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A39-01100				COVER, CRANKCASE SIDE	1	1	1				
2	32A39-21200				GASKET, SIDE COVER	1	1	1			A	
3	MF240051				BOLT, W/WASHER	14	14	14			A	


REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A40-00400				CARTRIDGE ASSY,OIL	1	1	1				
2	32A40-01101				UNION,OIL FILTER	1	1	1				






2009-05-26 615A30-00








REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	*				THERMOSTAT ASSY	1	1	1				
1 01	32A46-01101				COVER,THERMOSTAT	1	1	1				
1 02	32A46-01400				GASKET,THERMOSTAT	1	1	1			A	
1 03	32A46-02100				THERMOSTAT	1	1	1				
1 04	32A46-10030				CASE ASSY,THERMOSTAT	1	1	1				
1 05	*				PIPE,THERMOSTAT	1	1	1				
1 06	*				CASE,THERMOSTAT	1	1	1				
1 07	MF140227				BOLT,FLANGE	2	2	2			A	
2	32A46-01800				GASKET,THERMO CASE	1	1	1			A	
3	MF140239				BOLT,FLANGE	1	1	1			A	
4	MF140433				BOLT,FLANGE	1	1	1			A	
5	32A46-00900				HOSE,BY-PASS	1	1	1				
6	32A46-03100				CLAMP,HOSE	2	2	2				
7	MM316248				PLUG,DRAIN	2	2	2			A	
8	30636-25901				GASKET	2	2	2			A	




2009-05-26 615A30-00









REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	MD068353				NUT	4	4	4			A	
2	MD068355				GASKET,FUEL RETURN	4	4	4			A	
3	MD070717				GASKET,HOLDER	4	4	4			A	
4	MF240051				BOLT,W/WASHER	1	1	1			A	
5	32A61-08100				PIPE,INJECTION NO.1	1	1	1				
6	32A61-08200				PIPE,INJECTION NO.2	1	1	1				
7	32A61-08300				PIPE,INJECTION NO.3	1	1	1				
8	32A61-08400				PIPE,INJECTION NO.4	1	1	1				
9	MM430703				CLAMP	3	3	3				
10	MM430614				CLAMP	3	3	3				
11	MF243628				BOLT,W/WASHER	3	3	3			A	
12	32A61-04100				PIPE,FUEL LEAK OFF	1	1	1				
13	32A61-08701				PIPE,FUEL RETURN	1	1	1				
14	MM409276				HOSE ASSY,FUEL	1	1	1				
14 01	MS603016				HOSE,FUEL	1	1	1				
14 02	MS660164				CLIP,HOSE	2	2	2				




2009-05-26 615A30-00




2009-05-26 615A30-00





REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A61-01101				FLANGE, INJ PUMP	1	1	1				
2	06016-13140				O-RING	1	1	1			A	
3	30461-71601				GASKET, INJ PUMP	1	1	1			A	
4	MS401429				STUD	3	3	3				
5	05633-30800				NUT, FLANGE	3	3	3			A	
6	05633-31000				NUT, FLANGE	1	1	1			A	
7	MF241253				BOLT, W/WASHER	1	1	1			A	
8	32A61-08800				BRACKET, INJ PUMP	1	1	1				
9	32A61-08900				BRACKET, INJ PUMP	1	1	1				
10	F2005-10020				BOLT, W/WASHER	2	2	2			A	
11	F2500-10000				WASHER, PLAIN	2	2	2			A	
12	F1805-10025				BOLT, W/WASHER	1	1	1			A	
13	32A61-09600				WASHER	1	1	1			A	
14	32A13-02700				BOLT, FLANGE	1	1	1			A	
15	32A65-20910				PUMP ASSY, INJ	1	1	1				
					SEE G/N 65-03-02, -03							

65-03-02 INJECTION PUMP GENERAL



Ref. No. 134 Distributor head (Part Number 14640-14220)


Consists of 3 parts that are referred to by No. 134A, 134B, and 134C.

65-03-02 INJECTION PUMP GENERAL

- 81-

REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1 01	32A65-20910				PUMP ASSY, INJ	1	1	1				
1 02	14660-10900				OIL SEAL	1	1	1			A	
1 03	14610-00420				PUMP, FEED	1	1	1				
1 04	14610-30100				COVER	1	1	1				
1 05	13910-40000				SCREW	2	2	2			A	
1 06	14620-00020				SHAFT, DRIVE	1	1	1				
1 07	14620-00000				SHAFT, DRIVE	1	1	1				
1 08	14620-10000				KEY, WOODRUFF	1	1	1				
1 09	14620-20100				DAMPER	2	2	2				
1 10	91418-06161				BOLT, W/WASHER	6	6	6			A	
1 11	14620-30000				GEAR	1	1	1				
1 12	14620-40000				WASHER	1	1	1			A	
1 13	14621-02320				ROLLER ASSY	1	1	1				
1 14	14630-30000				PIN	1	1	1			A	
1 15	14630-40000				PIN	1	1	1			A	
1 16	14630-50000				CLIP	1	1	1			A	
1 17	14620-50000				DISK	1	1	1			A	
1 18	14622-04820				CAM, DISK	1	1	1				
1 19	14660-00800				O-RING	1	1	1			A	
1 20	14631-18920				PISTON	1	1	1			A	
1 21	14630-10000				SLIDER	1	1	1				
1 22	14631-26700				SPRING, TIMER	AR	AR	AR			A	
1 23	14631-26800				SPRING, TIMER	AR	AR	AR			A	
1 24	14631-26900				SPRING, TIMER	AR	AR	AR			A	
1 25	14669-03200				SHIM	AR	AR	AR			A	
1 26	14669-03300				SHIM	AR	AR	AR			A	
1 27	14669-03400				SHIM	AR	AR	AR			A	
1 28	14669-03500				SHIM	AR	AR	AR			A	
1 29	14669-04100				SHIM	AR	AR	AR			A	
1 30	14669-04200				SHIM	AR	AR	AR			A	
1 31	14669-04300				SHIM	AR	AR	AR			A	
1 32	14660-00800				O-RING	1	1	1			A	
1 33	14631-04020				COVER	1	1	1				
1 34	14662-05000				BOLT	2	2	2			A	
1 35	14631-00100				COVER	1	1	1				
1 36	14662-05000				BOLT	2	2	2				
1 37	14631-21900				SPRING, TIMER	1	1	1			A	
1 38	14623-00000				SHIM	1	1	1			A	
1 39	14623-00100				WASHER	1	1	1			A	
1 40	14623-10001				SEAT, SPRING	1	1	1				
1 41	14623-30000				SEAT, SPRING	2	2	2				
1 42	14660-30000				SHIM	AR	AR	AR			A	
1 43	14660-30100				SHIM	AR	AR	AR			A	
1 44	14660-30200				SHIM	AR	AR	AR			A	
1 45	14660-30300				SHIM	AR	AR	AR			A	
1 46	14660-30400				SHIM	AR	AR	AR			A	
1 47	14660-30500				SHIM	AR	AR	AR			A	
1 48	14660-30600				SHIM	AR	AR	AR			A	
1 49	14669-01400				SHIM	AR	AR	AR			A	
1 50	14669-01500				SHIM	AR	AR	AR			A	

65-03-02 INJECTION PUMP GENERAL




Ref. No. 134 Distributor head (Part Number 14640-14220)

Consists of 3 parts that are referred to by No. 134A, 134B, and 134C.

REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1 32	14669-01600				SHIM	T=1.30	AR	AR	AR			A
	14669-01700				SHIM	T=1.40	AR	AR	AR			A
	14669-01800				SHIM	T=1.60	AR	AR	AR			A
	14669-01900				SHIM	T=1.70	AR	AR	AR			A
	14669-05800				SHIM	T=2.10	AR	AR	AR			A
	14669-05900				SHIM	T=2.20	AR	AR	AR			A
	14669-06000				SHIM	T=2.30	AR	AR	AR			A
	14669-06100				SHIM	T=2.40	AR	AR	AR			A
	14669-06200				SHIM	T=2.50	AR	AR	AR			A
	14669-06300				SHIM	T=2.60	AR	AR	AR			A
	14669-06400				SHIM	T=2.70	AR	AR	AR			A
	14669-06500				SHIM	T=2.80	AR	AR	AR			A
	14669-06600				SHIM	T=2.90	AR	AR	AR			A
	14669-06700				SHIM	T=3.00	AR	AR	AR			A
	14669-06800				SHIM	T=3.10	AR	AR	AR			A
	14669-06900				SHIM	T=3.20	AR	AR	AR			A
	14669-07000				SHIM	T=3.30	AR	AR	AR			A
	14669-07100				SHIM	T=3.40	AR	AR	AR			A
	14669-07200				SHIM	T=0.40	AR	AR	AR			A
	14669-07300				SHIM	T=0.60	AR	AR	AR			A
1 33	14669-07400				SHIM	T=0.70	AR	AR	AR			A
	14669-07500				SHIM	T=1.90	AR	AR	AR			A
	14669-07800				SHIM	T=0.20	AR	AR	AR			A
	14623-40600				PIN, GUIDE		2	2	2			
	14640-14220				DISTRIBUTOR HEAD	(INCLUDING A&B&C)	1	1	1			
1 35	14660-00000				O-RING		1	1	1			A
1 36	14642-00000				SHIM	T=1.90	AR	AR	AR			A
	14642-00100				SHIM	T=1.92	AR	AR	AR			A
	14642-00200				SHIM	T=1.94	AR	AR	AR			A
	14642-00300				SHIM	T=1.96	AR	AR	AR			A
	14642-00400				SHIM	T=1.98	AR	AR	AR			A
	14642-00500				SHIM	T=2.00	AR	AR	AR			A
	14642-00600				SHIM	T=2.02	AR	AR	AR			A
	14642-00700				SHIM	T=2.04	AR	AR	AR			A
	14642-00800				SHIM	T=2.06	AR	AR	AR			A
	14642-00900				SHIM	T=2.08	AR	AR	AR			A
	14642-01000				SHIM	T=2.10	AR	AR	AR			A
	14642-01100				SHIM	T=2.12	AR	AR	AR			A
	14642-01200				SHIM	T=2.14	AR	AR	AR			A
	14642-01300				SHIM	T=2.16	AR	AR	AR			A
	14642-01400				SHIM	T=2.18	AR	AR	AR			A
	14642-01500				SHIM	T=2.20	AR	AR	AR			A
	14642-01600				SHIM	T=2.22	AR	AR	AR			A
	14642-01700				SHIM	T=2.24	AR	AR	AR			A
	14642-01800				SHIM	T=2.26	AR	AR	AR			A
	14642-01900				SHIM	T=2.28	AR	AR	AR			A
	14642-02000				SHIM	T=2.30	AR	AR	AR			A
	14642-02100				SHIM	T=2.32	AR	AR	AR			A
	14642-02200				SHIM	T=2.34	AR	AR	AR			A
	14642-02300				SHIM	T=2.36	AR	AR	AR			A


65-03-02 INJECTION PUMP GENERAL




Ref. No. 134 Distributor head (Part Number 14640-14220)

Consists of 3 parts that are referred to by No. 134A, 134B, and 134C.

REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1 36	14642-02400 14642-02500 14642-02600 14642-02700 14642-02800				SHIM SHIM SHIM SHIM SHIM T=2.38 T=2.40 T=2.42 T=2.44 T=2.46	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14642-02900 14642-03000 14642-03100 14642-03200 14642-03300				SHIM SHIM SHIM SHIM SHIM T=2.48 T=2.50 T=2.52 T=2.54 T=2.56	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14642-03400 14642-03500 14642-03600 14642-03700 14642-03800				SHIM SHIM SHIM SHIM SHIM T=2.58 T=2.60 T=2.62 T=2.64 T=2.66	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14642-03900 14642-04000 14642-04100 14642-04200 14642-04300				SHIM SHIM SHIM SHIM SHIM T=2.68 T=2.70 T=2.72 T=2.74 T=2.76	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14642-04400 14642-04500 14642-04600 14642-04700 14642-04800				SHIM SHIM SHIM SHIM SHIM T=2.78 T=2.80 T=2.82 T=2.84 T=2.86	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14642-04900 14642-05000 14642-05100 14642-05200 14642-05300				SHIM SHIM SHIM SHIM SHIM T=2.88 T=2.90 T=1.74 T=1.76 T=1.78	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14642-05400 14642-05500 14642-05600 14642-05700 14642-05800				SHIM SHIM SHIM SHIM SHIM T=1.80 T=1.82 T=1.84 T=1.86 T=1.88	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
1 37 1 38 1 39 1 40 1 41	14643-30100 14643-03320 14643-20000 14644-00220 13910-60100				GASKET VALVE, DELIVERY SPRING HOLDER SCREW	4 4 4 4 3	4 4 4 4 3	4 4 4 4 3			A A A A A	
1 42 1 43 1 44 1 45 1 46	14687-16920 14656-80000 02650-81140 14658-80500 14656-90300				LEVER, GOVERNOR BOLT, PIVOT GASKET SPRING NUT	1 2 2 2 1	1 2 2 2 1	1 2 2 2 1			A A A A A	
1 47 1 48 1 49	14657-00420 14660-00400 14657-10000 14657-10100 14657-10200				SHAFT, GOVERNOR O-RING SHIM SHIM SHIM T=1.05 T=1.25 T=1.45	1 1 AR AR AR	1 1 AR AR AR	1 1 AR AR AR			A A A A A	




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1 49	14657-10300 14657-10400 14657-10500 14657-10600 14657-10700				SHIM SHIM SHIM SHIM SHIM T=1.65 T=1.85 T=1.15 T=1.35 T=1.55	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
1 50 1 51 1 52 1 53	14657-10800 14660-20600 14657-20020 14660-29400 14697-63000				SHIM WASHER HOLDER, F.W WASHER SLEEVE, GOVERNOR T=1.75	AR 1 1 1 1	AR 1 1 1 1	AR 1 1 1 1			A A A A	
1 54 1 55	14657-60400 14657-70820 14657-70920 14657-71020 14657-71120				CAP PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING L=5.00 L=5.10 L=5.20 L=5.30	1 AR AR AR AR	1 AR AR AR AR	1 AR AR AR AR			A A A A A	
	14657-71220 14657-71320 14657-71420 14657-71520 14657-71620				PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING L=5.40 L=5.50 L=5.60 L=5.70 L=5.80	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14657-71720 14657-71820 14657-71920 14657-72020 14657-72120				PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING L=5.90 L=6.00 L=6.10 L=6.20 L=6.30	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14657-72220 14657-72320 14657-72420 14657-72520 14657-72620				PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING L=6.40 L=6.50 L=6.60 L=6.70 L=6.80	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14657-72720 14657-72820 14657-72920 14657-73020 14657-73120				PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING L=6.90 L=7.00 L=7.10 L=7.20 L=7.30	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14657-73220 14657-73320 14657-73420 14657-73520 14657-73620				PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING L=7.40 L=7.50 L=7.60 L=7.70 L=7.80	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
	14657-73720 14657-73820 14687-73920 14687-74020 14687-74120				PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING PLUG,CLOSING L=7.90 L=8.00 L=8.10 L=8.20 L=8.30	AR AR AR AR AR	AR AR AR AR AR	AR AR AR AR AR			A A A A A	
1 56 1 57 1 58 1 59	14687-74220 14687-96820 14658-00600 14642-10020 02650-81140				PLUG,CLOSING RETAINING PIN SPRING, GOV PLUG GASKET L=8.40	AR 1 1 1 1	AR 1 1 1 1	AR 1 1 1 1			A A A A	




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1 60	14642-20000				BOLT	1	1	1			A	
1 61	14660-00500				O-RING	1	1	1			A	
1 62	14660-00600				O-RING	1	1	1			A	
1 63	14660-00700				O-RING	1	1	1			A	
1 64	14611-03720				VALVE,REGULATING	1	1	1				
1 65	14611-40000				RING,SPRING	1	1	1				
1 66	14620-60100				SPRING	1	1	1			A	
1 67	14693-58601				BRACKET	1	1	1				
1 68	01020-62240				BOLT,SOCKET HEAD	2	2	2			A	
1 69	14662-00200				BOLT,SOCKET HEAD	1	1	1			A	
1 70	14665-01220				VALVE,MAGNET	1	1	1				
1 71	14660-01700				O-RING	1	1	1			A	
1 72	14666-21420				WIRE	1	1	1				
1 73	14662-14901				NUT	1	1	1			A	
1 74	13951-20500				GASKET	1	1	1			A	
1 75	14666-91720				EYE	1	1	1				
1 76	14612-50101				FILTER	1	1	1			A	
1 77	14612-50200				SPRING	1	1	1			A	
1 78	14602-01820				HOUSING,PUMP	1	1	1				
1 79	14623-20720				SPRING,PLUNGER KIT	1	1	1			A	
1 80	14657-41220				FLYWEIGHT ASSY	1	1	1				
1 81	14660-01120				REPAIR KIT	1	1	1				
1 82	14621-05720				ROLLER KIT	1	1	1				
1 83	14694-03400				PLATE,NUMBER	1	1	1				
1 84	02580-31640				KEY,WOODRUFF	1	1	1				
1 85	01302-12140				NUT	1	1	1			A	
1 86	01411-12440				WASHER,SPRING	1	1	1			A	
1 87	14659-88600				NUT,CAP	1	1	1				

65-03-03 INJECTION PUMP ASSY




REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	14682-23320				COVER,GOV	1	1	1				
1 01	14650-81022				COVER,GOV	1	1	1				
1 02	14681-50120				SHAFT,CONTROL	1	1	1				
1 03	14660-00100				O-RING	1	1	1			A	
1 04	13931-00200				WASHER	2	2	2			A	
1 05	14683-25500				LEVER	AR	AR	AR				
	14683-25600				LEVER	AR	AR	AR				
	14683-29300				LEVER	AR	AR	AR				
	14683-29400				LEVER	AR	AR	AR				
1 06	01411-06440				WASHER, SPRING	2	2	2			A	
1 07	01302-06040				NUT	1	1	1			A	
1 08	14651-51820				SHAFT, LEVER	1	1	1				
1 09	14658-74500				SPRING	1	1	1			A	
1 10	14660-00200				O-RING	1	1	1			A	
1 11	14660-20100				WASHER	1	1	1			A	
1 12	14654-01300				LEVER	AR	AR	AR				
	14654-01400				LEVER	AR	AR	AR				
	14654-05200				LEVER	AR	AR	AR				
	14654-05300				LEVER	AR	AR	AR				
1 13	14662-11700				NUT	1	1	1			A	
1 14	14662-11700				NUT	1	1	1			A	
1 15	14652-63400				BOLT	1	1	1			A	
1 16	14652-67300				SCREW	1	1	1			A	
1 17	14658-70400				SPRING	1	1	1			A	
1 18	14654-10000				ANGLE	1	1	1			A	
1 19	14692-52520				BRACKET	1	1	1				
1 20	13900-64500				BOLT	2	2	2			A	
1 21	01302-06040				NUT	1	1	1			A	
1 22	14660-04400				RING, SEAL	1	1	1				
1 23	13930-80300				WASHER	1	1	1			A	
1 24	14654-54600				SCREW, LOAD	AR	AR	AR				
	14654-54700				SCREW, LOAD	AR	AR	AR				
	14654-54800				SCREW, LOAD	AR	AR	AR				
1 25	14659-85000				NUT	1	1	1			A	
1 26	14660-01200				O-RING	1	1	1			A	
1 27	14654-54500				DAMPER	1	1	1				
2	13910-60200				SCREW	4	4	4			A	
3	14612-00120				OVER FLOW VALVE	1	1	1				
4	13951-20500				GASKET	2	2	2			A	
5	14659-87310				CAP	1	1	1				
6	14659-86710				CAP	1	1	1				
7	01402-06140				WASHER	1	1	1			A	
8	14659-86300				NUT, CAP	1	1	1				
9	14659-87320				CAP	1	1	1				
10	14659-87920				CAP	1	1	1				




PART WITHOUT REF. NO. WILL NOT BE SUPPLIED.


REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	01				STARTER ASSY	1	1	1				
1	02				BRACKET ASSY,FRONT	1	1	1				
1	03				BEARING SET	1	1	1			A	
1	04				SHAFT ASSY,CLUTCH	1	1	1				
1	05				SHAFT ASSY,GEAR	1	1	1				
1	06				WASHER SET	1	1	1			A	
1	07				GEAR ASSY,INTERNAL	1	1	1				
1	08				CLUTCH,OVER RUNNING	1	1	1				
1	09				GEAR ASSY	1	1	1				
1	10				LEVER ASSY	1	1	1				
1	11				PINION SET	1	1	1				
1	12				STOPPER SET	1	1	1				
1	13				SWITCH ASSY	1	1	1			A	
1	14				SCREW SET	1	1	1			A	
1	15				BALL	1	1	1				
1	16				PACKING SET	1	1	1			A	
1	17				ARMATURE SET	1	1	1				
1	18				BEARING	1	1	1			A	
1	19				YOKE ASSY	1	1	1				
1	20				HOLDER ASSY,BRUSH	1	1	1				
1	21				SPRING,BRUSH	4	4	4			A	
1	22				BRACKET ASSY,REAR	1	1	1				
1	23				BOLT SET	1	1	1			A	
1	24				BRUSH	2	2	2			A	



68-00-01 ALTERNATOR(FOR Y365DP,Y367DP)




68-00-02 ALTERNATOR(FOR Y368DP)




2009-05-26 615A30-00

68-00-03 ALTERNATOR(12V-50A)




PART WITHOUT REF.NO. WILL NOT BE SUPPLIED.

REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	32A68-00401				ALTERNATOR ASSY	1	1	1				
1 01	A981X-20771				NUT, LOCK	1	1	1			A	
1 02	A628X-65070				PULLEY ASSY	1	1	1				
1 03	A414X-19271				SCREW SET	1	1	1			A	
1 04	A640X-69170				BRACKET ASSY, FRONT	1	1	1				
1 05	A414X-21271				SCREW SET	1	1	1			A	
1 06	A930X-94570				BEARING, BALL	1	1	1			A	
1 07	A880X-91870				ROTOR ASSY	1	1	1				
1 08	S930P-63670				BEARING, BALL	1	1	1			A	
1 09	A383T-46370				STATOR ASSY	1	1	1				
1 10	*				BRACKET ASSY, REAR	1	1	1				
1 11	A866X-44682				REGULATOR SET	1	1	1				
1 12	A647X-50170				BRUSH SET	2	2	2			A	
1 13	A860X-50970				RECTIFIER ASSY	1	1	1				
1 14	A529X-05571				NUT SET	1	1	1			A	



**94-00-01 OVERHAUL GASKET KIT
(FOR Y365DP,Y367DP)**




**94-00-01 OVERHAUL GASKET KIT
(FOR Y365DP,Y367DP)**

-105-

REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1 01	32A94-10040				GASKET KIT,OVERHAUL	1	1	•				
1 02	05507-10110				O-RING	1	1	•			A	
1 03	05946-00601				WASHER,SEALING	8	8	•			A	
1 04	05946-00801				GASKET	1	1	•			A	
1 05	05946-01001				WASHER,SEALING	2	2	•			A	
1 06	05946-01201				WASHER,SEALING	2	2	•			A	
1 07	05946-01401				WASHER,SEALING	10	10	•			A	
1 08	06016-13075				O-RING	1	1	•			A	
1 09	06016-13140				O-RING	2	2	•			A	
1 10	30636-25901				GASKET	3	3	•			A	
1 11	30661-51300				GASKET	1	1	•			A	
1 12	32A01-02204				GASKET,CYLINDER HEAD	1	1	•			A	
1 13	32A01-02501				GASKET,HEAD REAR	1	1	•			A	
1 14	32A04-02801				SEAL,VALVE STEM	8	8	•			A	
1 15	32A04-13200				GASKET	1	1	•			A	
1 16	32A07-04100				GASKET,FRONT PLATE	1	1	•			A	
1 17	32A07-11700				SEAL,SIDE	2	2	•			A	
1 18	32A07-14201				GASKET,REAR	1	1	•			A	
1 19	32A11-00200				GASKET,GEAR CASE	1	1	•			A	
1 20	32A30-00201				GASKET,INLET MANF	1	1	•			A	
1 21	32A32-00200				GASKET,EXHAUST MANF	1	1	•			A	
1 22	32A32-01400				GASKET	1	1	•			A	
1 23	32A32-03300				GASKET	1	1	•			A	
1 24	32A35-00600				O-RING	1	1	•			A	
1 25	32A39-21200				GASKET	1	1	•			A	
1 26	32A39-11400				GASKET	1	1	•			A	
1 27	32A45-10400				GASKET	1	1	•			A	
1 28	32A45-10500				GASKET,WATER PUMP	1	1	•			A	
1 29	32A46-01400				GASKET,THERMOSTAT	1	1	•			A	
1 30	32A61-56900				GASKET,NOZZLE	4	4	•			A	
1 31	32A90-13600				GASKET	1	1	•			A	
1 32	32A91-05100				GASKET,LIQUID	1	1	•			A	
1 33	34232-00300				GASKET	1	1	•			A	
1 34	34330-04300				GASKET	1	1	•			A	
1 35	34336-04100				GASKET	1	1	•			A	
1 36	34340-00700				GASKET	1	1	•			A	
1 37	32A46-01800				GASKET	1	1	•			A	
1 38	F3150-02000				O-RING	3	3	•			A	
1 39	F3156-02500				GASKET	2	2	•			A	
1 40	F4202-08000				GASKET	4	4	•			A	
1 41	F4202-10000				GASKET	2	2	•			A	
1 42	F4202-14000				GASKET	1	1	•			A	
1 43	F4202-18000				GASKET	2	2	•			A	
1 44	MD068355				GASKET,FUEL RETURN	4	4	•			A	
1 45	MD070717				GASKET,HOLDER	4	4	•			A	
1 46	MM432045				GASKET	4	4	•			A	
1 47	MM433993				O-RING	1	1	•			A	
1 48	32A07-04500				GASKET	1	1	•			A	
1 49	32A11-10700				GASKET	1	1	•			A	
1 50	32A39-14100				GASKET	1	1	•			A	

94-00-01 OVERHAUL GASKET KIT
(FOR Y365DP,Y367DP)




94-00-01 OVERHAUL GASKET KIT
(FOR Y365DP,Y367DP)

-107-

REF. -NO.		PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION		MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
								Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1	50	05507-00090				O-RING	NOT SHOWN	4	4	•			A	
1	51	05507-00280				O-RING	NOT SHOWN	2	2	•			A	

94-00-02 OVERHAUL GASKET KIT
(FOR Y368DP)



**94-00-02 OVERHAUL GASKET KIT
(FOR Y368DP)**

-109-

REF. -NO.	PART NO.	R / P	S E Q	C N G	PART NAME & DESCRIPTION	MODEL & QTY			APPLICABLE SERIAL NO.		M / R	V R D
						Y365DP	Y367DP	Y368DP	FROM@-	-@UPTO		
1 01	32A94-11040				GASKET KIT,OVERHAUL	•	•	1				
1 02	32A01-02204				GASKET,CYLINDER HEAD	•	•	1			A	
1 03	32A01-02501				GASKET,HEAD REAR	•	•	1			A	
1 04	32A04-02801				SEAL,VALVE STEM	•	•	8			A	
1 05	32A04-13200				GASKET	•	•	1			A	
1 06	32A07-11700				SEAL,SIDE	•	•	2			A	
1 07	32A07-14201				GASKET,REAR	•	•	1			A	
1 08	32A07-04100				GASKET	•	•	1			A	
1 09	32A11-22201				GASKET,GEAR CASE	•	•	1			A	
	F4202-14000				GASKET	•	•	1			A	
1 10	30461-71601				GASKET	•	•	1			A	
1 11	32A30-00201				GASKET	•	•	1			A	
1 12	32A32-00200				GASKET	•	•	1			A	
1 13	32A35-00600				O-RING	•	•	1			A	
1 14	F3150-02000				O-RING	•	•	1			A	
1 15	34340-00700				GASKET	•	•	1			A	
1 16	F4202-18000				GASKET	•	•	1			A	
1 17	32A39-21200				GASKET	•	•	1			A	
1 18	32A45-10500				GASKET,WATER PUMP	•	•	1			A	
1 19	32A46-01400				GASKET,THERMOSTAT	•	•	1			A	
1 20	34446-05300				GASKET	•	•	1			A	
1 21	MD068355				GASKET,FUEL RETURN	•	•	4			A	
1 22	MD070717				GASKET,HOLDER	•	•	4			A	
1 23	06016-13140				O-RING	•	•	2			A	
1 24	06016-13080				O-RING	•	•	1			A	
1 25	30636-25901				GASKET	•	•	1			A	
1 26	34330-04300				GASKET	•	•	1			A	
1 27	32A32-01400				GASKET	•	•	1			A	
1 28	F3153-07500				O-RING	•	•	2			A	
1 29	32A45-10400				GASKET	•	•	1			A	
1 30	32A91-05100				GASKET,LIQUID	•	•	1				
1 31	32A61-53900				GASKET	•	•	1			A	
1 32	32B32-00800				GASKET,EXHAUST	•	•	1			A	
1 33	63663-00701				GASKET	•	•	1			A	
1 34	32A07-04500				GASKET	•	•	1			A	
1 35	32A46-01800				GASKET	•	•	1			A	

NUMERICAL PARTS INDEX

PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.
A383T-46370	68-00-03	101	1 09	M191X-67685	66	93	1 07	MF241251	11-00-02	19	3
A414X-19271	68-00-03	101	1 03	M230X-00671	66	93	1 08	MF241251	35-02	49	3
A414X-21271	68-00-03	101	1 05	M357X-66185	66	93	1 04	MF241253	65-03-01	79	7
A529X-05571	68-00-03	101	1 14	M357X-91874	66	93	1 03	MF241255	04	7	8 11
A628X-65070	68-00-03	101	1 02	M372X-02871	66	93	1 12	MF241255	48-02	67	1
A640X-69170	68-00-03	101	1 04	M385X-03771	66	93	1 11	MF241257	62	77	2
A647X-50170	68-00-03	101	1 12	M391X-04371	66	93	1 20	MF241261	04-02	9	3
A860X-50970	68-00-03	101	1 13	M414X-04875	66	93	1 13	MF241261	30	41	3
A866X-44682	68-00-03	101	1 11	M578X-29171	66	93	1 15	MF241262	45	59	3
A880X-91870	68-00-03	101	1 07	M605X-96571	66	93	1 10	MF241264	11-00-01	17	6
A930X-94570	68-00-03	101	1 06	M641X-B1571	66	93	1 01	MF241264	11-00-02	19	6
A981X-20771	68-00-03	101	1 01	M642X-35671	66	93	1 21	MF241266	11-00-01	17	9
F1035-08020	32	45	3	M648X-40771	66	93	1 23	MF241266	11-00-02	19	9
F1035-08090	30	41	4	M649X-20471	66	93	1 19	MF241280	23-00-01	35	5
F1035-12035	21	33	2	M690X-00572	66	93	1 02	MF241280	23-00-02	37	5
F1805-08025	45	59	1 06	M800X-73771	66	93	1 18	MF241282	12	21	4
F1805-08035	45	59	1 07	M863X-08673	66	93	1 09	MF241284	12	21	5
F1805-10025	65-03-01	79	12	M901X-00371	66	93	1 22	MF241284	68-00-01	97	3
F2005-10020	65-03-01	79	10	M982X-38871	66	93	1 05	MF241284	68-00-02	99	3
F2005-10025	21	33	7	MC880900	90	103	1	MF243628	61-00-01	71	11
F2300-10000	12	21	8	MD000269	07	13	13	MF407726	12	21	7
F2320-10000	35	47	4	MD000312	12	21	13	MF522010	04	7	8 12
F2325-08000	04	7	8 07	MD001404	12	21	12	MM316248	01	3	6
F2500-10000	65-03-01	79	11	MD001521	68-00-01	97	6	MM316248	12	21	10
F2515-08000	30	41	5	MD001521	68-00-02	99	6	MM316248	46	63	7
F2515-10000	12	21	9	MD008784	04-02	9	4	MM409276	61-00-01	71	14
F2515-10000	35	47	5	MD050316	13	23	1 02	MM430614	61-00-01	71	10
F2515-12000	21	33	3	MD050317	13	23	1 03	MM430703	61-00-01	71	9
F2846-05000	07	13	9	MD068353	61-00-01	71	1	MM432045	94-00-01	105	1 45
F2846-10000	20	29	1 02	MD068355	61-00-01	71	2	MM433993	94-00-01	105	1 46
F2846-10000	20	29	2 02	MD068355	94-00-01	105	1 43	MS401429	65-03-01	79	4
F2846-12000	07	13	8	MD068355	94-00-02	109	1 21	MS603016	61-00-01	71	14 01
F2850-04008	07	13	10	MD070717	61-00-01	71	3	MS660164	61-00-01	71	14 02
F2870-07022	05	11	2	MD070717	94-00-01	105	1 44	MS661140	07	13	14
F2870-07022	20	29	1 03	MD070717	94-00-02	109	1 22	MS661142	07	13	15
F2870-07022	20	29	2 03	ME015735	48	65	1	S409S-00008	66	93	1 14
F3150-02000	35-02	49	2	MF140026	68-00-01	97	5	S930P-29970	66	93	1 17
F3150-02000	94-00-01	105	1 37	MF140026	68-00-02	99	5	S930P-63670	68-00-03	101	1 08
F3150-02000	94-00-02	109	1 14	MF140227	46	63	1 07	01020-62240	65-03-02	89	1 68
F3153-07500	25	39	2	MF140239	46	63	3	01302-06040	65-03-03	91	1 07
F3153-07500	94-00-02	109	1 28	MF140433	46	63	4	01302-06040	65-03-03	91	1 21
F3156-02500	94-00-01	105	1 38	MF240051	01-02	5	4	01302-12140	65-03-02	89	1 85
F3202-03000	17	25	8	MF240051	13	23	2	01402-06140	65-03-03	91	7
F4202-08000	94-00-01	105	1 39	MF240051	25	39	3	01411-06440	65-03-03	91	1 06
F4202-10000	94-00-01	105	1 40	MF240051	39	53	3	01411-12440	65-03-02	89	1 86
F4202-14000	94-00-01	105	1 41	MF240051	61-00-01	71	4	02580-31640	65-03-02	89	1 84
F4202-14000	94-00-02	109	1 09	MF240053	01-02	5	5	02650-81140	65-03-02	85	1 44
F4202-18000	94-00-01	105	1 42	MF240053	35	47	3	02650-81140	65-03-02	87	1 59
F4202-18000	94-00-02	109	1 16	MF240053	62	77	4	04826-21200	04	7	8 02
F8004-06008	25	39	4	MF240054	30-02	43	3	04826-21800	07	13	3
M106X-43571	66	93	1 16	MF241251	05	11	4	04826-22000	01	3	2 01
M135X-01581	66	93	1 06	MF241251	11-00-01	17	4	04826-22500	01	3	2 02

NUMERICAL PARTS INDEX

PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.
04826-23500	07	13	2 01	09317-51920	61-00-02	73	1 07	14630-30000	65-03-02	81	1 12
04827-90170	07	13	4	09317-51930	61-00-02	73	1 07	14630-40000	65-03-02	81	1 13
05507-00090	94-00-01	107	1 50	09317-51940	61-00-02	73	1 07	14630-50000	65-03-02	81	1 14
05507-00280	94-00-01	107	1 51	09317-51950	61-00-02	73	1 07	14631-00100	65-03-02	81	1 25
05507-10110	94-00-01	105	1 01	09317-51960	61-00-02	73	1 07	14631-04020	65-03-02	81	1 23
05605-01410	07	13	11	09317-51970	61-00-02	73	1 07	14631-18920	65-03-02	81	1 18
05633-30800	65-03-01	79	5	09317-51980	61-00-02	73	1 07	14631-21900	65-03-02	81	1 27
05633-31000	65-03-01	79	6	09317-51990	61-00-02	73	1 07	14631-26700	65-03-02	81	1 20
05910-20045	49	69	1	09317-52000	61-00-02	73	1 07	14631-26800	65-03-02	81	1 20
05946-00601	94-00-01	105	1 02	09317-52010	61-00-02	73	1 07	14631-26900	65-03-02	81	1 20
05946-00801	94-00-01	105	1 03	09317-52020	61-00-02	73	1 07	14640-14220	65-03-02	83	1 34
05946-01001	94-00-01	105	1 04	09317-52030	61-00-02	73	1 07	14642-00000	65-03-02	83	1 36
05946-01201	94-00-01	105	1 05	09317-52040	61-00-02	73	1 07	14642-00100	65-03-02	83	1 36
05946-01401	94-00-01	105	1 06	09317-52050	61-00-02	73	1 07	14642-00200	65-03-02	83	1 36
06016-13075	94-00-01	105	1 07	09317-52060	61-00-02	73	1 07	14642-00300	65-03-02	83	1 36
06016-13080	25	39	7	09317-52070	61-00-02	73	1 07	14642-00400	65-03-02	83	1 36
06016-13080	94-00-02	109	1 24	09317-52080	61-00-02	73	1 07	14642-00500	65-03-02	83	1 36
06016-13140	11-00-01	17	8	09317-52090	61-00-02	73	1 07	14642-00600	65-03-02	83	1 36
06016-13140	11-00-02	19	8	13900-64500	65-03-03	91	1 20	14642-00700	65-03-02	83	1 36
06016-13140	65-03-01	79	2	13910-40000	65-03-02	81	1 04	14642-00800	65-03-02	83	1 36
06016-13140	94-00-01	105	1 08	13910-60100	65-03-02	85	1 41	14642-00900	65-03-02	83	1 36
06016-13140	94-00-02	109	1 23	13910-60200	65-03-03	91	2	14642-01000	65-03-02	83	1 36
09311-07780	61-00-02	73	1 02	13930-80300	65-03-03	91	1 23	14642-01100	65-03-02	83	1 36
09312-10380	61-00-02	73	1 03	13931-00200	65-03-03	91	1 04	14642-01200	65-03-02	83	1 36
09312-70360	61-00-02	73	1 04	13951-20500	65-03-02	89	1 74	14642-01300	65-03-02	83	1 36
09316-40951	61-00-02	73	1 05	13951-20500	65-03-03	91	4	14642-01400	65-03-02	83	1 36
09317-40070	61-00-02	73	1 06	14602-01820	65-03-02	89	1 78	14642-01500	65-03-02	83	1 36
09317-51670	61-00-02	73	1 07	14610-00420	65-03-02	81	1 02	14642-01600	65-03-02	83	1 36
09317-51680	61-00-02	73	1 07	14610-30100	65-03-02	81	1 03	14642-01700	65-03-02	83	1 36
09317-51690	61-00-02	73	1 07	14611-03720	65-03-02	89	1 64	14642-01800	65-03-02	83	1 36
09317-51700	61-00-02	73	1 07	14611-40000	65-03-02	89	1 65	14642-01900	65-03-02	83	1 36
09317-51710	61-00-02	73	1 07	14612-00120	65-03-03	91	3	14642-02000	65-03-02	83	1 36
09317-51720	61-00-02	73	1 07	14612-50101	65-03-02	89	1 76	14642-02100	65-03-02	83	1 36
09317-51730	61-00-02	73	1 07	14612-50200	65-03-02	89	1 77	14642-02200	65-03-02	83	1 36
09317-51740	61-00-02	73	1 07	14620-00000	65-03-02	81	1 06	14642-02300	65-03-02	83	1 36
09317-51750	61-00-02	73	1 07	14620-00020	65-03-02	81	1 05	14642-02400	65-03-02	85	1 36
09317-51760	61-00-02	73	1 07	14620-10000	65-03-02	81	1 07	14642-02500	65-03-02	85	1 36
09317-51770	61-00-02	73	1 07	14620-20100	65-03-02	81	1 08	14642-02600	65-03-02	85	1 36
09317-51780	61-00-02	73	1 07	14620-30000	65-03-02	81	1 09	14642-02700	65-03-02	85	1 36
09317-51790	61-00-02	73	1 07	14620-40000	65-03-02	81	1 10	14642-02800	65-03-02	85	1 36
09317-51800	61-00-02	73	1 07	14620-50000	65-03-02	81	1 15	14642-02900	65-03-02	85	1 36
09317-51810	61-00-02	73	1 07	14620-60100	65-03-02	89	1 66	14642-03000	65-03-02	85	1 36
09317-51820	61-00-02	73	1 07	14621-02320	65-03-02	81	1 11	14642-03100	65-03-02	85	1 36
09317-51830	61-00-02	73	1 07	14621-05720	65-03-02	89	1 82	14642-03200	65-03-02	85	1 36
09317-51840	61-00-02	73	1 07	14622-04820	65-03-02	81	1 16	14642-03300	65-03-02	85	1 36
09317-51850	61-00-02	73	1 07	14623-00000	65-03-02	81	1 28	14642-03400	65-03-02	85	1 36
09317-51860	61-00-02	73	1 07	14623-00100	65-03-02	81	1 29	14642-03500	65-03-02	85	1 36
09317-51870	61-00-02	73	1 07	14623-10001	65-03-02	81	1 30	14642-03600	65-03-02	85	1 36
09317-51880	61-00-02	73	1 07	14623-20720	65-03-02	89	1 79	14642-03700	65-03-02	85	1 36
09317-51890	61-00-02	73	1 07	14623-30000	65-03-02	81	1 31	14642-03800	65-03-02	85	1 36
09317-51900	61-00-02	73	1 07	14623-40600	65-03-02	83	1 33	14642-03900	65-03-02	85	1 36
09317-51910	61-00-02	73	1 07	14630-10000	65-03-02	81	1 19	14642-04000	65-03-02	85	1 36

NUMERICAL PARTS INDEX

PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.
14642-04100	65-03-02	85	136	14657-70820	65-03-02	87	155	14660-01200	65-03-03	91	126
14642-04200	65-03-02	85	136	14657-70920	65-03-02	87	155	14660-01700	65-03-02	89	171
14642-04300	65-03-02	85	136	14657-71020	65-03-02	87	155	14660-04400	65-03-03	91	122
14642-04400	65-03-02	85	136	14657-71120	65-03-02	87	155	14660-10900	65-03-02	81	101
14642-04500	65-03-02	85	136	14657-71220	65-03-02	87	155	14660-20100	65-03-03	91	111
14642-04600	65-03-02	85	136	14657-71320	65-03-02	87	155	14660-20600	65-03-02	87	150
14642-04700	65-03-02	85	136	14657-71420	65-03-02	87	155	14660-29400	65-03-02	87	152
14642-04800	65-03-02	85	136	14657-71520	65-03-02	87	155	14660-30000	65-03-02	81	132
14642-04900	65-03-02	85	136	14657-71620	65-03-02	87	155	14660-30100	65-03-02	81	132
14642-05000	65-03-02	85	136	14657-71720	65-03-02	87	155	14660-30200	65-03-02	81	132
14642-05100	65-03-02	85	136	14657-71820	65-03-02	87	155	14660-30300	65-03-02	81	132
14642-05200	65-03-02	85	136	14657-71920	65-03-02	87	155	14660-30400	65-03-02	81	132
14642-05300	65-03-02	85	136	14657-72020	65-03-02	87	155	14660-30500	65-03-02	81	132
14642-05400	65-03-02	85	136	14657-72120	65-03-02	87	155	14660-30600	65-03-02	81	132
14642-05500	65-03-02	85	136	14657-72220	65-03-02	87	155	14662-00200	65-03-02	89	169
14642-05600	65-03-02	85	136	14657-72320	65-03-02	87	155	14662-05000	65-03-02	81	124
14642-05700	65-03-02	85	136	14657-72420	65-03-02	87	155	14662-05000	65-03-02	81	126
14642-05800	65-03-02	85	136	14657-72520	65-03-02	87	155	14662-11700	65-03-03	91	113
14642-10020	65-03-02	87	158	14657-72620	65-03-02	87	155	14662-11700	65-03-03	91	114
14642-20000	65-03-02	89	160	14657-72720	65-03-02	87	155	14662-14901	65-03-02	89	173
14643-03320	65-03-02	85	138	14657-72820	65-03-02	87	155	14665-01220	65-03-02	89	170
14643-20000	65-03-02	85	139	14657-72920	65-03-02	87	155	14666-21420	65-03-02	89	172
14643-30100	65-03-02	85	137	14657-73020	65-03-02	87	155	14666-91720	65-03-02	89	175
14644-00220	65-03-02	85	140	14657-73120	65-03-02	87	155	14669-01400	65-03-02	81	132
14650-81022	65-03-03	91	101	14657-73220	65-03-02	87	155	14669-01500	65-03-02	81	132
14651-51820	65-03-03	91	108	14657-73320	65-03-02	87	155	14669-01600	65-03-02	83	132
14652-63400	65-03-03	91	115	14657-73420	65-03-02	87	155	14669-01700	65-03-02	83	132
14652-67300	65-03-03	91	116	14657-73520	65-03-02	87	155	14669-01800	65-03-02	83	132
14654-01300	65-03-03	91	112	14657-73620	65-03-02	87	155	14669-01900	65-03-02	83	132
14654-01400	65-03-03	91	112	14657-73720	65-03-02	87	155	14669-03200	65-03-02	81	121
14654-05200	65-03-03	91	112	14657-73820	65-03-02	87	155	14669-03300	65-03-02	81	121
14654-05300	65-03-03	91	112	14658-00600	65-03-02	87	157	14669-03400	65-03-02	81	121
14654-10000	65-03-03	91	118	14658-70400	65-03-03	91	117	14669-03500	65-03-02	81	121
14654-54500	65-03-03	91	127	14658-74500	65-03-03	91	109	14669-04100	65-03-02	81	121
14654-54600	65-03-03	91	124	14658-80500	65-03-02	85	145	14669-04200	65-03-02	81	121
14654-54700	65-03-03	91	124	14659-85000	65-03-03	91	125	14669-04300	65-03-02	81	121
14654-54800	65-03-03	91	124	14659-86300	65-03-03	91	8	14669-05800	65-03-02	83	132
14656-80000	65-03-02	85	143	14659-86710	65-03-03	91	6	14669-05900	65-03-02	83	132
14656-90300	65-03-02	85	146	14659-87310	65-03-03	91	5	14669-06000	65-03-02	83	132
14657-00420	65-03-02	85	147	14659-87320	65-03-03	91	9	14669-06100	65-03-02	83	132
14657-10000	65-03-02	85	149	14659-87920	65-03-03	91	10	14669-06200	65-03-02	83	132
14657-10100	65-03-02	85	149	14659-88600	65-03-02	89	187	14669-06300	65-03-02	83	132
14657-10200	65-03-02	85	149	14660-00000	65-03-02	83	135	14669-06400	65-03-02	83	132
14657-10300	65-03-02	87	149	14660-00100	65-03-03	91	103	14669-06500	65-03-02	83	132
14657-10400	65-03-02	87	149	14660-00200	65-03-03	91	110	14669-06600	65-03-02	83	132
14657-10500	65-03-02	87	149	14660-00400	65-03-02	85	148	14669-06700	65-03-02	83	132
14657-10600	65-03-02	87	149	14660-00500	65-03-02	89	161	14669-06800	65-03-02	83	132
14657-10700	65-03-02	87	149	14660-00600	65-03-02	89	162	14669-06900	65-03-02	83	132
14657-10800	65-03-02	87	149	14660-00700	65-03-02	89	163	14669-07000	65-03-02	83	132
14657-20020	65-03-02	87	151	14660-00800	65-03-02	81	117	14669-07100	65-03-02	83	132
14657-41220	65-03-02	89	180	14660-00800	65-03-02	81	122	14669-07200	65-03-02	83	132
14657-60400	65-03-02	87	154	14660-01120	65-03-02	89	181	14669-07300	65-03-02	83	132

NUMERICAL PARTS INDEX

PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.
14669-07400	65-03-02	83	1 32	32A04-04011	04	7	8 01	32A17-02010	17	25	4
14669-07500	65-03-02	83	1 32	32A04-04701	04	7	8 04	32A17-02020	17	25	5
14669-07800	65-03-02	83	1 32	32A04-04801	04	7	8 05	32A17-02030	17	25	6
14681-50120	65-03-03	91	1 02	32A04-09100	04-02	9	1 01	32A17-08300	17	25	7
14682-23320	65-03-03	91	1	32A04-09100	30	41	1 01	32A17-10100	17	25	1
14683-25500	65-03-03	91	1 05	32A04-13012	04-02	9	1	32A17-10200	17	25	2
14683-25600	65-03-03	91	1 05	32A04-13200	04-02	9	2	32A17-10300	17	25	3
14683-29300	65-03-03	91	1 05	32A04-13200	94-00-01	105	1 14	32A19-00012	19	27	1
14683-29400	65-03-03	91	1 05	32A04-13200	94-00-02	109	1 04	32A19-00400	19	27	1 04
14687-16920	65-03-02	85	1 42	32A04-20100	04	7	1	32A19-00501	19	27	1 05
14687-73920	65-03-02	87	1 55	32A04-21100	04	7	2	32A19-09011	19	27	2
14687-74020	65-03-02	87	1 55	32A04-22010	04	7	8 06	32A19-09021	19	27	3
14687-74120	65-03-02	87	1 55	32A05-00101	05	11	1	32A19-09031	19	27	4
14687-74220	65-03-02	87	1 55	32A05-02101	05	11	5	32A19-09041	19	27	5
14687-96820	65-03-02	87	1 56	32A05-13100	05	11	6	32A20-00044	20	29	2
14692-52520	65-03-03	91	1 19	32A07-01501	07	13	7	32A20-00052	20	29	1
14693-58601	65-03-02	89	1 67	32A07-02600	07	13	2 04	32A20-02203	20-02	31	1
14694-03400	65-03-02	89	1 83	32A07-04100	11-00-01	17	3	32A20-02902	20	29	1 04
14697-63000	65-03-02	87	1 53	32A07-04100	11-00-02	19	2	32A20-02902	20	29	2 04
30405-31403	05	11	3	32A07-04100	94-00-01	105	1 15	32A21-00051	21	33	1
30461-71601	65-03-01	79	3	32A07-04100	94-00-02	109	1 07	32A21-00900	21	33	1 01
30461-71601	94-00-02	109	1 10	32A07-04500	94-00-01	105	1 47	32A21-00900	21	33	4 01
30604-21402	04	7	3	32A07-04500	94-00-02	109	1 34	32A23-00200	20	29	2 05
30604-31601	04	7	4	32A07-11700	07	13	16	32A23-00301	20	29	1 05
30619-10501	19	27	1 01	32A07-11700	94-00-01	105	1 16	32A23-01101	23-00-01	35	1
30636-25901	01	3	7	32A07-11700	94-00-02	109	1 05	32A23-01200	23-00-02	37	1
30636-25901	12	21	11	32A07-14201	12	21	3	32A23-02900	23-00-02	37	2
30636-25901	46	63	8	32A07-14201	94-00-01	105	1 17	32A23-03030	23-00-02	37	3
30636-25901	94-00-01	105	1 09	32A07-14201	94-00-02	109	1 06	32A23-03040	23-00-01	35	3
30636-25901	94-00-02	109	1 25	32A07-41010	07	13	1	32A23-03200	23-00-01	35	3 02
30661-51300	94-00-01	105	1 10	32A09-00010	09	15	1	32A23-03200	23-00-02	37	3 02
31304-11700	04	7	6	32A09-00020	09	15	2	32A23-03500	07	13	12
31345-12100	48	65	2	32A09-00030	09	15	3	32A23-05101	23-00-01	35	2
31A90-00701	90	103	2	32A09-00040	09	15	4	32A23-07100	25	39	6
32A01-01400	01	3	4	32A11-00200	11-00-01	17	5	32A23-24101	25	39	5
32A01-01600	01	3	2 03	32A11-00200	94-00-01	105	1 18	32A30-00201	30	41	2
32A01-02204	01	3	5	32A11-01100	11-00-01	17	7	32A30-00201	94-00-01	105	1 19
32A01-02204	94-00-01	105	1 11	32A11-01100	11-00-02	19	7	32A30-00201	94-00-02	109	1 11
32A01-02204	94-00-02	109	1 01	32A11-02901	25	39	1	32A30-16012	30	41	1
32A01-02501	01-02	5	3	32A11-04010	11-00-01	17	10	32A32-00200	32	45	2
32A01-02501	94-00-01	105	1 12	32A11-04010	11-00-02	19	10	32A32-00200	94-00-01	105	1 20
32A01-02501	94-00-02	109	1 02	32A11-10100	11-00-01	17	2	32A32-00200	94-00-02	109	1 12
32A01-02700	01-02	5	1	32A11-10700	94-00-01	105	1 48	32A32-00600	32	45	1
32A01-02800	01-02	5	2	32A11-22201	11-00-02	19	5	32A32-01400	94-00-01	105	1 21
32A01-03100	01	3	2 04	32A11-22201	94-00-02	109	1 08	32A32-01400	94-00-02	109	1 27
32A01-03200	01	3	2 05	32A11-23100	11-00-01	17	1	32A32-03300	94-00-01	105	1 22
32A01-21020	01	3	1	32A11-32103	11-00-02	19	4	32A35-00600	35	47	2
32A03-01100	01	3	2 07	32A11-33201	11-00-02	19	1	32A35-00600	94-00-01	105	1 23
32A04-02401	04	7	8 08	32A13-00011	13	23	1	32A35-00600	94-00-02	109	1 13
32A04-02801	04	7	7	32A13-02700	65-03-01	79	14	32A35-10012	35	47	1
32A04-02801	94-00-01	105	1 13	32A13-02700	68-00-01	97	2	32A35-12101	23-00-01	35	6
32A04-02801	94-00-02	109	1 03	32A13-02700	68-00-02	99	2	32A35-16101	35-02	49	1

NUMERICAL PARTS INDEX

PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.	PART NO.	GROUP NO.	PAGE	REF. NO.
32A35-22202	23-00-02	37	6	32A68-00401	68-00-03	101	1				
32A36-00500	25	39	8	32A68-01103	68-00-01	97	1				
32A36-05012	36	51	1	32A68-10500	68-00-02	99	1				
32A36-10400	25	39	9	32A68-11601	68-00-01	97	4				
32A39-01100	39	53	1	32A68-11701	68-00-02	99	4				
32A39-11400	94-00-01	105	1 25	32A90-13600	94-00-01	105	1 30				
32A39-14100	94-00-01	105	1 49	32A91-05100	94-00-01	105	1 31				
32A39-21200	39	53	2	32A91-05100	94-00-02	109	1 30				
32A39-21200	94-00-01	105	1 24	32A94-10040	94-00-01	105	1				
32A39-21200	94-00-02	109	1 17	32A94-11040	94-00-02	109	1				
32A40-00400	40	55	1	32B09-08101	09	15	5				
32A40-01101	40	55	2	32B09-08201	09	15	6				
32A42-05100	13	23	3	32B09-08301	09	15	7				
32A43-01700	43	57	1	32B12-00301	12	21	1				
32A45-00300	45	59	1 01	32B12-00700	12	21	2				
32A45-01300	45	59	1 03	32B21-05010	21	33	4				
32A45-01600	45	59	1 04	32B21-05200	21	33	6				
32A45-10400	45	59	1 02	32B32-00800	94-00-02	109	1 32				
32A45-10400	94-00-01	105	1 26	32B45-02101	45-02	61	1				
32A45-10400	94-00-02	109	1 29	32B45-10032	45	59	1				
32A45-10500	45	59	2	32C04-04501	04	7	8 10				
32A45-10500	94-00-01	105	1 27	32C61-07000	61-00-02	73	1				
32A45-10500	94-00-02	109	1 18	32C61-07010	61-00-02	73	1 01				
32A46-00900	46	63	5	34232-00300	94-00-01	105	1 32				
32A46-01101	46	63	1 01	34232-08300	32	45	4				
32A46-01400	46	63	1 02	34307-02100	07	13	6				
32A46-01400	94-00-01	105	1 28	34323-00801	23-00-01	35	4				
32A46-01400	94-00-02	109	1 19	34323-00801	23-00-02	37	4				
32A46-01800	46	63	2	34330-04300	30-02	43	2				
32A46-01800	94-00-01	105	1 36	34330-04300	94-00-01	105	1 33				
32A46-01800	94-00-02	109	1 35	34330-04300	94-00-02	109	1 26				
32A46-02100	46	63	1 03	34336-04100	94-00-01	105	1 34				
32A46-03100	46	63	6	34340-00700	36	51	2				
32A46-10030	46	63	1 04	34340-00700	94-00-01	105	1 35				
32A61-01101	65-03-01	79	1	34340-00700	94-00-02	109	1 15				
32A61-04100	61-00-01	71	12	34404-02901	04	7	5				
32A61-08100	61-00-01	71	5	34407-11090	12	21	6				
32A61-08200	61-00-01	71	6	34446-05300	94-00-02	109	1 20				
32A61-08300	61-00-01	71	7	34462-01050	62	77	1 01				
32A61-08400	61-00-01	71	8	34462-01060	62	77	1 02				
32A61-08701	61-00-01	71	13	34462-01070	62	77	1 03				
32A61-08800	65-03-01	79	8	34462-11030	62	77	1 04				
32A61-08900	65-03-01	79	9	34462-21040	62	77	1 05				
32A61-09600	65-03-01	79	13	34462-30030	62	77	1				
32A61-53900	94-00-02	109	1 31	34661-02000	61-00-02	75	1 08				
32A61-56900	94-00-01	105	1 29	36730-01101	30-02	43	1				
32A62-00601	62	77	3	63663-00701	94-00-02	109	1 33				
32A65-20910	65-03-01	79	15	91418-06161	65-03-02	81	1 09				
32A65-20910	65-03-02	81	1	92233-31600	21	33	5				
32A66-03101	66-02	95	1								
32A66-04101	66-02	95	2								
32A66-10101	66	93	1								

615A3000

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1805-06010	F1035-06010 F2515-06000	F1805-06035	F1035-06035 F2515-06000	F1805-08018	F1035-08018 F2515-08000
F1805-06012	F1035-06012 F2515-06000	F1805-06040	F1035-06040 F2515-06000	F1805-08020	F1035-08020 F2515-08000
F1805-06014	F1035-06014 F2515-06000	F1805-06045	F1035-06045 F2515-06000	F1805-08022	F1035-08022 F2515-08000
F1805-06016	F1035-06016 F2515-06000	F1805-06055	F1035-06055 F2515-06000	F1805-08025	F1035-08025 F2515-08000
F1805-06018	F1035-06018 F2515-06000	F1805-06060	F1035-06060 F2515-06000	F1805-08030	F1035-08030 F2515-08000
F1805-06020	F1035-06020 F2515-06000	F1805-08012	F1035-08012 F2515-08000	F1805-08035	F1035-08035 F2515-08000
F1805-06025	F1035-06025 F2515-06000	F1805-08014	F1035-08014 F2515-08000	F1805-08040	F1035-08040 F2515-08000
F1805-06030	F1035-06030 F2515-06000	F1805-08016	F1035-08016 F2515-08000	F1805-08045	F1035-08045 F2515-08000

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1805-08050	F1035-08050 F2515-08000	F1805-10018	F1035-10018 F2515-10000	F1805-10050	F1035-10050 F2515-10000
F1805-08055	F1035-08055 F2515-08000	F1805-10020	F1035-10020 F2515-10000	F1805-10055	F1035-10055 F2515-10000
F1805-08060	F1035-08060 F2515-08000	F1805-10022	F1035-10022 F2515-10000	F1805-10060	F1035-10060 F2515-10000
F1805-08065	F1035-08065 F2515-08000	F1805-10025	F1035-10025 F2515-10000	F1805-10065	F1035-10065 F2515-10000
F1805-08070	F1035-08070 F2515-08000	F1805-10030	F1035-10030 F2515-10000	F1805-10070	F1035-10070 F2515-10000
F1805-08075	F1035-08075 F2515-08000	F1805-10035	F1035-10035 F2515-10000	F1805-10085	F1035-10085 F2515-10000
F1805-10014	F1035-10014 F2515-10000	F1805-10040	F1035-10040 F2515-10000	F1805-12016	F1035-12016 F2515-12000
F1805-10016	F1035-10016 F2515-10000	F1805-10045	F1035-10045 F2515-10000	F1805-12020	F1035-12020 F2515-12000

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1805-12025	F1035-12025 F2515-12000	F1805-12065	F1035-12065 F2515-12000	F1825-06010	F1035-06010 F2515-06000 F2500-06000
F1805-12030	F1035-12030 F2515-12000	F1805-12085	F1035-12085 F2515-12000	F1825-06012	F1035-06012 F2515-06000 F2500-06000
F1805-12035	F1035-12035 F2515-12000	F1805-14035	F1035-14035 F2515-14000	F1825-06014	F1035-06014 F2515-06000 F2500-06000
F1805-12040	F1035-12040 F2515-12000	F1805-14045	F1035-14045 F2515-14000	F1825-06016	F1035-06016 F2515-06000 F2500-06000
F1805-12045	F1035-12045 F2515-12000			F1825-06020	F1035-06020 F2515-06000 F2500-06000
F1805-12050	F1035-12050 F2515-12000			F1825-06025	F1035-06025 F2515-06000 F2500-06000
F1805-12055	F1035-12055 F2515-12000				
F1805-12060	F1035-12060 F2515-12000				

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1825-06030	F1035-06030	F1825-08025	F1035-08025	F1825-08050	F1035-08050
	F2515-06000		F2515-08000		F2515-08000
	F2500-06000		F2500-08000		F2500-08000
F1825-06035	F1035-06035	F1825-08030	F1035-08030	F1825-08055	F1035-08055
	F2515-06000		F2515-08000		F2515-08000
	F2500-06000		F2500-08000		F2500-08000
F1825-06055	F1035-06055	F1825-08035	F1035-08035	F1825-08085	F1035-08085
	F2515-06000		F2515-08000		F2515-08000
	F2500-06000		F2500-08000		F2500-08000
F1825-08012	F1035-08012	F1825-08038	F1035-08038	F1825-10014	F1035-10014
	F2515-08000		F2515-08000		F2515-10000
	F2500-08000		F2500-08000		F2500-10000
F1825-08016	F1035-08016	F1825-08040	F1035-08040	F1825-10016	F1035-10016
	F2515-08000		F2515-08000		F2515-10000
	F2500-08000		F2500-08000		F2500-10000
F1825-08020	F1035-08020	F1825-08045	F1035-08045	F1825-10020	F1035-10020
	F2515-08000		F2515-08000		F2515-10000
	F2500-08000		F2500-08000		F2500-10000

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F1825-10025	F1035-10025	F1825-12025	F1035-12025	F2005-10016	F1155-10016
	F2515-10000		F2515-12000		F2515-10000
	F2500-10000		F2500-12000		
F1825-10030	F1035-10030	F1825-12030	F1035-12030	F2005-10020	F1155-10020
	F2515-10000		F2515-12000		F2515-10000
	F2500-10000		F2500-12000		
F1825-10035	F1035-10035	F1825-12040	F1035-12040	F2005-10025	F1155-10025
	F2515-10000		F2515-12000		F2515-10000
	F2500-10000		F2500-12000		
F1825-10040	F1035-10040			F2005-10030	F1155-10030
	F2515-10000				F2515-10000
	F2500-10000				
F1825-10080	F1035-10040			F2005-10035	F1155-10035
	F2515-10000				F2515-10000
	F2500-10000				
F1825-10080	F1035-10080			F2005-10040	F1155-10040
	F2515-10000				F2515-10000
	F2500-10000				
F1825-12020	F1035-10080			F2005-10045	F1155-10045
	F2515-10000				F2515-10000
	F2500-10000				
F1825-12020	F1035-12020			F2005-10050	F1155-10050
	F2515-12000				F2515-10000
	F2500-12000				

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F2005-10055	F1155-10055 F2515-10000	F2005-12040	F1155-12040 F2515-12000	F2015-10020	F1155-10020 F2515-10000 F2500-10000
F2005-10060	F1155-10060 F2515-10000	F2005-12045	F1155-12045 F2515-12000	F2015-10025	F1155-10025 F2515-10000 F2500-10000
F2005-10065	F1155-10065 F2515-10000	F2005-12050	F1155-12050 F2515-12000	F2015-10030	F1155-10030 F2515-10000 F2500-10000
F2005-10070	F1155-10070 F2515-10000	F2005-12055	F1155-12055 F2515-12000	F2015-10035	F1155-10035 F2515-10000 F2500-10000
F2005-12020	F1155-12020 F2515-12000	F2005-12065	F1155-12065 F2515-12000	F2015-10040	F1155-10040 F2515-10000 F2500-10000
F2005-12025	F1155-12025 F2515-12000			F2015-10050	F1155-10050 F2515-10000 F2500-10000
F2005-12030	F1155-12030 F2515-12000				
F2005-12035	F1155-12035 F2515-12000				

TABLE OF BOLT,W/WASHER

BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER	BOLT,W/WASHER	BOLT/WASHER
F2015-10055	F1155-10055 F2515-10000 F2500-10000				
F2015-10060	F1155-10060 F2515-10000 F2500-10000				
F2015-12025	F1155-12025 F2515-12000 F2500-12000				
F2015-12030	F1155-12030 F2515-12000 F2500-12000				